

product instructions

assembly:

instructions (even ours) can be boring, so we've tried to keep them short:

1. remove OmniBoost from bag, unfold, and lock rear legs into place.
- 2a. securely fasten the safety straps around adult chair and insert your little one.
- 2b. for increased stability (perhaps you're out at a park or a beach), try using our "duck-feet". they slide over the normal feet and help prevent tip-overs... like those that happen when your great dane decides to sit in your baby's lap at lunchtime.
3. to attach the tray, simply drop it into place over the small mushroom-shaped heads on either side of the chair arms. ensure the tray is firmly locked down. to fully remove or to swivel the tray, pull out one or both of the side levers, and you are good to go.

washing:

1. remove the tray.
2. remove the cover.
 - it's easier to remove the cover if your OmniBoost is partially collapsed.
 - remember to unhook the elastic straps at the base of each fabric corner.
 - the cover is tight on purpose, but the holes are definitely large enough to fit over the posts.
3. machine wash cover (**no bleach!**) using cold setting. allow to air dry.

final word:

we hope you love your OmniBoost as much as we loved designing it. lots of hours (and caffeine) were put into its design, and we are incredibly proud of it. look for more new things from us soon! and please, if you like hiccapop - spread the word. if you don't like us... please forget we said anything. thanks!

adult chair minimum dimensions: 17" wide x 17" length x 18" backrest height

WARNING

Children have suffered **head injuries**, including skull fractures, **after falling** with or from booster seats.

- Check that OmniBoost is **securely attached** to adult chair before each use.
- **Always use restraints** until child is able to get in and out of OmniBoost without help. Adjust to **fit snugly**.
- **Never** allow child to **push away from table**.
- **Never lift** and **carry** child in OmniBoost.
- **Stay near** and **watch** your child during use.

Prevent falls from adult chairs:

Securely attach OmniBoost using **all** provided safety straps (under and behind).

WARNING

Until Child is able to get in and out of the OmniBoost without help (about 2 ½ years old), the child should be secured in the booster seat at all times by the restraining system. The tray is not designed to hold the child in the chair.

WARNING

Use this product only for children capable of sitting upright unassisted.

WARNING

Prevent serious injury or death:
Do not use in motor vehicles.