

Luvele

Luv life. Luv health.

LUVELE FRESH VACUUM CANISTER
- FOUR PIECE SET -



Instruction
Booklet
LFVC4SETUSA



PLASTIC-FREE FOOD STORAGE

Luvele.com

Safety

Please be sure to read all instructions before using the Luvele Fresh Vacuum Canister set. Keep these instructions for future reference.

The included Portable Hand Pump is intended to be exclusively used with Luvele glass canisters to create an effective vacuum seal for long-lasting food storage. It may only be used with the accessories supplied or approved by Luvele. Any other use is considered improper and may result in personal injury or property damage. The Hand Pump is intended for domestic use only. It is not intended for commercial use. Do not use the appliance on yourself, other persons or animals.

- Remove all packaging material before using your canister set for the first time.
- Do not place your canister set near the edge of a bench or table during operation. Ensure the surface is level, free of liquids or other substances.
- Use only the provided attachments to vacuum seal the glass canisters.
- Improper handling of the Hand Pump causes the risk of fire. Only charge the battery using the included connecting cable. Do not disassemble the battery.
- Make sure that the connecting cable is not knotted or pinched and make sure that the connecting cable and the Hand Pump do not come in contact with sources of heat (e.g. hobs, gas flames).
- Always unplug the power adapter from the socket, do not pull the connecting cable.
- In the event of danger or a defect, unplug the power adapter connected to the connecting cable from the socket immediately.
- Unplug the Hand Pump from the connecting cable prior to cleaning or maintenance .
- **IMPORTANT:** As long as the power adapter is plugged in, there is a voltage inside the appliance, even if the Hand Pump is switched off.
- Never remove the connecting cable with wet hands, lay the cable on a hot surface, or let the cable come into contact with oil.
- Never dismantle the Hand Pump and do not make any technical modifications.
- Never use a faulty appliance or faulty accessories.
- Do not try and perform any maintenance, other than cleaning. For any maintenance issues please contact Luvele USA at support@luvele.com
- Do not operate outdoors.
- Do not microwave canisters with the lid on.
- Use a fire blanket only to extinguish fires on appliance.
- The appliance is not designed for commercial or industrial use, it is for household use only.

Congratulations

on the purchase of your new Luvele Fresh Vacuum Canister Set



Safety

This appliance is intended to be used in household and similar applications such as:

- Staff kitchen areas in shops, offices and other working environments;
- Farm houses;
- By clients in hotels, motels and other residential type environments;
- Bed and breakfast type environments

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children 8 years and above can use this appliance, however, they should be supervised to ensure that they do not play with the appliance. Children should not play with the appliance.

Cleaning and user maintenance shall not be made by children unless they are older than 8 years old and supervised.

Keep the appliance and its connecting cable out of reach of children less than 8 years.

Keep children away from the packaging material. It poses a risk of suffocation. The device has a permanently installed battery.

Use only designated accessories enclosed.

Please be sure to read all of the following instructions before using the Luvele Fresh Vacuum Canister set. Keep the instructions for future reference.

Introduction

The Luvele Fresh Vacuum Canister Set lets you enjoy the convenience and benefits of storing pre-made meals, preserving leftovers, controlling portion sizes and simplifying reheating in a vacuum sealed, plastic free environment, allowing food to last up to 3-5 times longer.

They are great for storing foods or other items in the refrigerator, freezer or in the pantry.

The glass canisters are dishwasher, oven and microwave safe (without lids). Use the glass canisters to cook meals in the oven (without lid), or reheat your left over in the microwave (without lid).

Hand Pump Technical Information:

Battery Specification : 3.7V, Li-Ion, 1500mA

Power : 2.5W

Charging cable : Type C, Length 1.0m (3.2 ft)

Charge current: 500mA

Charge time : ~ 4 hours

Dimensions (DxH) : 5.5cm * 13cm (2.1 in * 5.1 in)

Net Weight: 0.3 kg (0.6 lbs)

Material : Stainless steel + ABS plastic, Silicone

Items Included:

1x Portable Hand Pump

1x Hand Pump Storage case

1x Connecting Cable (USB power point adaptor not included)

1x 450ml (15.2 oz) Glass Canister

1x 750ml (25.3 oz) Glass Canister

1x 1300ml (43.9 oz) Glass Canister

1x 2500ml (84.5 oz) Glass Canister

Features

Air Release Valve

Press down fully when vacuum sealing. To release the vacuum pressure, place your finger on the Air Release Valve and pull back slowly.

Food Grade Stainless Steel Lid

Made with high quality 304 stainless steel for plastic free food storage.

Stackable System

The stainless steel lid is designed with a flat surface to make the canisters stackable.



Borosilicate Glass - Canister Base

The glass canister base can be used in the oven and microwave oven. It is dishwasher safe and can be stored in the freezer.

Silicone Seal

Medical grade, non-toxic silicone seal.



WARNING:

Do not wash lid in a dishwasher. Do not place in a microwave.
Do not put in an oven.

Features

Portable Hand Pump

Use the battery powered, Portable Hand Pump to vacuum seal your canisters at home or on the go.



Storage Case

The convenient padded storage case will protect your Hand Pump and Connecting Cable during storage.



TYPE C USB Connecting Cable

Use the Connecting Cable to recharge the Hand Pump. Simply plug it into an existing USB charge point.




Features

The Hand Pump sits over the Air Release Valve, and when activated will create a vacuum in the canister.



Glass Canister Sizes

There are four sizes of Luvele Fresh Vacuum Canisters included, the 450ml (15.2oz), 750ml (25.3oz), 1300ml (43.9oz) and 2500ml (84.5oz).



For Sale

Packs of three glass canisters are available in each size for separate purchase at [luvele.com](https://www.luvele.com).

Visit our website today to expand your plastic-free storage capacity. Spare parts and accessories also available.



3x450ml
(15.2oz)

3x750ml
(25.3oz)

3x1300ml
(43.9oz)

3x2500ml
(84.5oz)

Operation

Vacuum Sealing Canisters with the Portable Hand Pump



IMPORTANT:

Charge the Hand Pump fully before the first use.
Follow instruction on page 11.

STEP 1

Place the Hand Pump over the Air Release Valve on the canister lid.

STEP 2

Press the On/Off button on the Hand Pump and press down lightly for 2 seconds until it grips. The white LED power light will turn on.

STEP 3

Remove your hand and allow the Hand Pump to vacuum seal the canister.

STEP 4

The vacuum sealing will stop automatically when the vacuum pressure reaches the optimal level. The white LED light will turn off.

STEP 5

Remove the Hand Pump and store canister.

NOTE:

The vacuum sealing process can be manually stopped at any time by pressing the On/Off button.

NOTE:


The duration of the vacuum sealing process depends on the size of the canister and it's content. For example, if a canister is smaller or more full, the vacuum sealing process is faster.

NOTE:

Do not touch the Air Release Valve during storage.

Operation

Charging the Portable Hand Pump



IMPORTANT:
Charge the Hand Pump fully before the first use.

NOTE:
To maintain optimal battery function, charge the Hand Pump at least once every 3 to 6 months.

STEP 1 Connect the included TYPE C USB Connecting Cable to an existing USB charging point or plug, and the charging port on the side of the Hand Pump.

STEP 2 The red LED power light will begin to flash slowly.

STEP 3 Charging may take up to 4 hours.

STEP 4 When the Hand Pump is fully charged, the LED power light will turn white and stop flashing.

STEP 5 Disconnect the Connecting Cable and the Hand Pump is ready for use.

Operation

Preparing a Canister for Vacuum Sealing

STEP 1 When placing food or liquids into a glass canister be sure not to overload the canister. Check the Silicon Seal and Air Release Valve are clean from any food or liquid debris.

IMPORTANT:
Make sure the food inside the canister does not come in contact with the Air Release Valve on the inside of the lid. We recommend a 2cm gap between the bottom of the Air Release Valve on the inside of the lid and the food in the canister.

STEP 2 Press the lid down firmly onto the glass canister, then make sure the air release valve is pressed down completely flat.

STEP 3 Follow the instructions on page 10, to vacuum seal the canister.

To release the vacuum pressure, place your finger on the Air Release Valve and pull back slowly. The air pressure will be released; it is now ready to remove the lid.



Tips

Make sure there are no crumbs or food debris on the canister lid or Air Release Valve, as gaps or an improper seal will prevent air from being removed.

Do not overfill the canister with food or liquid.

Easily cook food in an oven or microwave in your glass canister, simply remove the lid and place the glass canister in your oven or microwave.

Some deformation of the canister lid may occur during vacuuming. This is normal and does not affect performance.



IMPORTANT:

Do not vacuum seal soft cheese, mushrooms, onions or garlic.

The Luvele Fresh Vacuum Canisters can be used in the freezer.

Cruciferous vegetables such as broccoli, cauliflower, cabbage and brussels sprouts give off gases when they are stored. Vegetables should be blanched before vacuum sealing in bags or canisters. This process stops the enzyme action that could lead to loss of flavour, colour and texture.

Store the vacuum sealed canister in an upright position.



IMPORTANT:

Vacuum sealing food is not a substitute for refrigeration or freezing. Any perishable foods that require refrigeration must still be refrigerated after vacuum sealing.

Cleaning

Cleaning the Hand Pump



IMPORTANT:

Do not vacuum seal soft cheese, mushrooms, onions or garlic.

STEP 1

Only use a dry or slightly damp cloth to clean the body of the Hand Pump. DO NOT submerge in water.



IMPORTANT:

Do not put any parts of the Hand Pump into the dishwasher.

STEP 2

To clean the Silicone Seal, remove it from the body of the Hand Pump by gently pulling downwards and clean it with warm soapy water. Dry thoroughly before placing it back into position.

Cleaning the Stainless Steel Lids

Wash the stainless steel lids in warm, soapy water, rinse well and dry thoroughly.




IMPORTANT:

Do not wash the stainless steel lids in a dishwasher.

Cleaning the Glass Canisters

The glass canisters can be safely washed in the top rack of the dishwasher. You can also wash them in warm soapy water, then rinse well and dry thoroughly.



Warranty

Luvele Fresh Vacuum Canisters are backed by our 1 Year Total Cover Warranty. Our warranty will cover any manufacturing fault with the product and will also cover damage caused during transit.

Your warranty starts from the purchase date of your Luvele product. Please visit [luvele.com](https://www.luvele.com) to register your warranty. Further instructions can be found on your warranty card.



Warranty

Warranty Process

We want to make any warranty claim as simple as possible for you. All you need to do is contact us at support@luvele.com and provide us information about the problem you are having with your item. Firstly, we will suggest some troubleshooting ideas to establish whether or not the issue can be fixed without a return. Photos and videos of the fault may be requested if and where appropriate, and if it will ensure a faster resolution.

Generally, if you have an issue with your item within 30 days of receiving it, we will email you a prepaid return label that can be printed out and used to send the item back with. We will then generally send you a brand new item. The new item will be shipped within 48 hours of receiving the faulty item back. A confirmation email will be sent when your faulty item is received back.

If you have an issue after the 30 day period we will consider repairing your item if suitable. If it cannot be repaired it will be replaced with a brand new item. Refunds will only be offered within the 30 day money back guarantee, if you choose this option over a new replacement. Outside of this 30 day period, your item will be repaired or replaced.

We are here to help, so please email us and the best solution to meet your needs will be offered. support@luvele.com | [luvele.com](https://www.luvele.com)

Notes

