




OPERATION INSTRUCTIONS

SOUP KETTLE MODEL: GSB-12

Specification

Capacity: 14Qt/13L
Voltage: 110V 60Hz AC / 220-240V / 50-60Hz AC
Power: 600W
Weight: 13.2Lb/6Kg
Dimension: 16.2" H x 14.8" Dia. / 410mm H x 375mm Dia.



Operating and Maintenance:

- * Plug unit into correct electrical socket.
- * Use with WET HEAT ONLY. Add 28Oz/0.8L of water between the stainless steel liner and the internal aluminum container. Never overfill with water and under no circumstances should the stainless steel liner float up, even when empty. Remove any excess water immediately.
- * The temperature control should be set between 1 and 8. Always operate the kettle at the lowest setting to maintain correct serving temperature. Hold at high temperature by setting the control between 8 and 12.
- * A neon light will glow when the unit is turned on. Turn the dial to 0 to switch off. Unplug from the wall when not in use.
- * Always keep the removable hinged lid attached and in the closed position when not serving.
- * Never move or carry the kettle when unit is switched on, or when containing hot food.
- * Spilled food should be removed immediately from all exterior surfaces. The painted exterior and top collar should be wiped over with a damp soapy cloth.
- * Ensure the unit is unplugged when not in use, when filling and when being cleaned.
- * The kettle can not be cleaned with a high pressure jet.

IMPORTANT: NEVER IMMERSE KETTLE IN WATER OR OTHER LIQUID AS DAMAGE TO THE UNIT WILL RESULT AND ALL WARRANTIES WILL BE VOIDED.

WARNING: THIS APPLIANCE MUST BE GROUNDED.

WARNING: DO NOT OPERATE KETTLE EMPTY.

General Foodservice

Weston, FL 33331, U.S.A. - Phone:(954) 202-7419 · Fax:(954) 202-7337 - www.generalfoodservice.com