ACCUSPLIT. PRO SURVIVOR™

STOPWATCH A601X



STOPWATCH OPERATIONS

Press C until at STOPWATCH display. If necessary, Press R-Stop and L-Reset the stopwatch to zero.

<u>Event</u>	<u>Split</u>	1 <u>-2 Finish</u>
R-Start	R-Start	R-Start
R-Stop	L-Split	L-Stop #1
(Repeat R,R	L-Release	R-Stop #2
Time-in/	(Repeat L,L	(See #1 time)
Time-out)	each Split)	L-Release
L-Reset	R-Stop	(See #2 time)
	L-Reset	L-Reset

TIME AND CALENDAR DISPLAY

- Press C to select Time of Day mode.
- Hold R to display Month, Date and PM indicator (P).

TO SET TIME AND CALENDAR

- Hold C for 3 seconds and enter TIME SET MODE.
- Press R to select Minutes, Hour, Seconds, Month and Date.
- Press L to change any of the above. (Select a "blank" in the field after (P), not a Stopwatch indicator.) Seconds only resets to 00. Hold L to advance digits rapidly.
- Press C to return to TIME display.

TO SELECT 12/24 HOUR TIME DISPLAY

- Hold R and Press C to interchange 12P or 24 Hour Format
- Hold R and Press L to interchange MM DD or DD MM Format

BATTERY CHANGING:

If the display becomes dim or goes blank, you can replace the battery using the instructions posted at www.accusplit.com/support.
The watch uses a five-year CR2032 Lithium battery.

DUAL WARRANTY: 5 Year No Proof of Purchase or Proof of Purchase Limited Warranty.

See label on back of unit for details, or check support at ACCUSPLIT.com

REGISTER NOW

Please return your A601X Registration to the Repair Center address in the warranty, and we will let you know about future products.

· Email (preferred)

User Name

SPECIFICATIONS

Batteries should last for 5 years. If display becomes dim, open back and replace with CR2032 Battery.

Operating Temperature: 14°F to 138°F(–10° to 59°C).

Quartz Crystal Accuracy: 0.04sec/hr (accuracy may vary with shock, temperature or aging of crystal).

ACCUSPLIT, Inc. Pleasanton, CA 94588 USA 800-935-1996 • 925-290-1900 • FAX 925-290-1930

support@accusplit.com www.accusplit.com ASSEMBLED IN PRChina
© 2015 ACCUSPLIT