

# **INSTALLATION GUIDE** MODEL #: EOL-WL11BRZ-1030e


Lantern Class



## Questions?

For customer service please call us at 1-888-743-5766 Office Hours: 8:00 a.m. - 5:00 p.m. PST Monday-Friday

#### PLEASE REVIEW THE INSTRUCTIONS AND WARNINGS LISTED BELOW PRIOR TO PROPER INSTALLATION



## **WARNINGS**

- · Risk of fire / electrical shock
- LED Fixture installation requires knowledge of luminaire electrical systems.
- Risk of electric shock disconnect power at source before installation
- · Do not make or alter any open holes in an enclosure of wiring or electrical components during installation.
- If lamp or luminaire exhibits abnormal operation (buzzing, flickering, minimal light, etc.), turn off power, remove fixture and contact us. For more information please visit www.eurilighting.com or call our toll-free number 1-888-743-5766.

## **CAUTIONS**

- Do not look directly at the operating LED Fixture.
- Do not touch this product with wet hands.
- Do not disassemble, repair or alter lamp.
- Designed for outdoor applications only.
- Suitable for wet locations.
- The luminaires shall be grounded.
- Be careful not to touch the lamp pins to the metal housing when installing.
- This Device is not intended for use with emergency exits or emergency lights.

#### **INSTALLATION INSTRUCTIONS**

- 1. Use screws(2) install mounting plate(2) Junction box(1) (junction box not included)
- 2. Use wire cap(5)(6)(7) connect wire.
- 3. Install the fixture body(8), and put on the rubber ring to screw(4), install the screw nut cap tightly.
- 4. Done.

