

Assembly Instructions

IMPORTANT

DO NOT RETURN THIS BATTING CAGE TO THE RETAIL STORE WHERE PURCHASED. **CALL TOLL FREE: (800) 492-9334**


IMPORTANT WARRANTY WARNING:

DO NOT LEAVE THE XTENDER CAGE ASSEMBLED DURING STRONG WINDS, HEAVY SNOW, SLEET, OR ICE STORMS. THE XTENDER IS NOT DESIGNED TO WITHSTAND EXTREME WEATHER CONDITIONS AND DAMAGE TO THE FIBERGLASS FRAMES CAUSED BY EXTREME WEATHER MAY NOT BE COVERED IN THE MANUFACTURERS WARRANTY.

WARNING:


USE THIS PRODUCT WITH ADULT SUPERVISION ONLY. SERIOUS BODILY INJURY MAY OCCUR!





Rope Stake


Part# E (Quantity 2) - 14' Long Black Rope with Loop on the End Note: Make Sure Stakes Are Perfectly Straight Up And Down.



Do Not Return This Product To The Store. Call Toll Free: 1-800-492-9334 For Customer Service.

STEP 2: End Pole Assemblies (**Quantity 2**) (Refer to Part #'s Below.)


Slide each section together and tape together. Repeat for the second End Pole Assembly.




Tape each section together with Black Tape.

STEP 3: Middle Pole Assembly (**Quantity 1**) (Refer to Part #'s Below.)


Slide each section together and tape together.




Part# G
Tape each section together with Black Tape.




STEP 7: Hammer Rope Stake (Part# I) into ground and clip Stabilizer Rope into Rope Stake hole (6X). Make sure rope is tight.



Repeat for all (4) corners.






OPTIONAL ACCESSORY (Sold Separately):

You can purchase any Heater Sports Pitching Machine product to attach to the Xtender Home Batting Cage. Call Toll Free: 1-800-492-9334 to locate a retail store near you.

STEP 10:



WARNING

Make sure Heater Sports Pitching Machine is turned off and unplugged when attaching Batting Cage Net Harness Tube to Heater Sports Pitching Machine.


WARNING!

- Never allow a batter in the Batting Cage until the Heater Sports Pitching Machine has been sighted in and pitching at the desired target and at the right speed.
- Make sure Heater Sports
 Pitching Machine is turned
 off and unplugged when
 attaching the Batting Cage Net
 Harness Tube to the Trend
 Sports Pitching Machine.
- Make sure and disassemble the Xtender Batting Cage in stormy weather. The cage could break or blow over and cause property damage.
- Make sure area around batting cage is clear of people except for batter and machine operator. Bodily injury could occur if proper safety precautions aren't followed.


Xtender24'

Optional: Joining 2 Cages

(Must purchase 2 separate cages)
INSTRUCTIONS




Joining 2 Cages INSTRUCTIONS



Joining 2 Cages INSTRUCTIONS

Step #4



After cutting the netting on both cages take the extra netting and attach it to the end of the cage opposite the Pitching Machine Harness. This extra netting will provide additional support and cushioning to the backstop area.