


The REDARC Enhanced Lighting Controller is to be used when you do not have a dimming circuit to connect your gauge to or the dimming circuit in your vehicle does not dim the REDARC gauge to your liking. In some installations the GA-ELC will dim in reverse to the vehicle's dash lighting (ie, darker gauge when the dash brightens or vice-versa).

The below diagrams show how to wire the GA-ELC to enable dimming the correct way.



TECH TIP

Copyright 2016 REDARC Electronics Pty Ltd. All Rights Reserved