

CARPET SHAMPOO PROCEDURE

seat.

TIME STANDARD: 15 - 20 MINUTES

TIME STANDARD: 15 - 20 MINUTES		<u>: 15 - 20 MINUTES </u>
Applicatio	n Product/Tools	Procedure/Pro Tips
Vehicle Prep		Place keys on top of the driver's front tire. Remove trash & place customer belongings in clear plastic bag Remove mats and place to the side
Dry Brush		 Using 15" Carpet Brush agitate to loosen dirt, hair, and lint. Use caution while working under seat. Start at the driver's front working around the car counter clockwise
Vacuum Blow out		 Using compressed air, blow out cracks and crevices using Venturi Blow Gun. Use caution around gauges and loose plastic parts. While blowing out crevices use Long Vent Brush to agitate crevices. Compressed air should be directed away from the operator and towards the rear of the vehicle. After moving counter clockwise with air stream all debri should be in the passenger floorboard. Begin vacuuming at the driverside moving counter clockwise around the vehicle.
Pre-Spot Agitate	BINETS IN THE STATE OF THE STAT	 Identify spots on carpet and spray with Carpet & Upholstery Spotter. Using Upholstery Brush scrub spots. PRO TIPS: After scrubbing carpet with brush lay Microfiber Towel (folded) over spot and striking towel with Upholstery Brush, spot will appear on the Microfiber Towel. Lightly Spray Carpet & Upholstery Shampoo on to carpet let dwell for 30 seconds and scrub using DA Polisher and Rotary Carpet Brush.
Towel Agitate		 Rub carpet with Microfiber Towel to blot up any excess moisture in the carpet. Re-vacuum carpet and move counter clockwise to the next area, until inside of vehicle is completely finshed. Place customer belongings on the passenger