


E112 Switch Back

2-6098 High Low Switch



2-7061 Auxiliary Pump to Heater Switch Harness

- 1a. **E112 switch**, connect heater speed leads to corresponding dual spade connections on harness and switch back.
 - Yellow #1 (fan lead LOW)
 - Red #2 (fan lead MEDIUM)
 - Orange #3 (fan lead HIGH)
- 1b. **2-6098 switch**, connect heater speed leads to corresponding dual spade connections on harness and switch back.
 - Yellow #1 (fan lead LOW)
 - Orange #3 (fan lead HIGH)
2. Connect pump and + red wire to #87 on replay using female spade connector.
3. Connect - black ground wire to #85 on relay.
4. Connect + 12V power supply to #30 on relay.



6672 W Boekel Rd
 Rathdrum, ID 83858
 contactus@heatercraft
 208-687-4400 PST