



GameSir • Gaming is Winning.™

© 2019 GameSir Inc. All rights reserved.
Product may vary slightly from those pictures.

GameSir G5

Gaming Controller

User Manual ►



OPTIMIZE THE PERFORMANCE OF YOUR GAMESIR EQUIPMENT

Make your GameSir equipment more powerful with GameSir G-Crux, the highly-integrated hardware configuration tool that takes your GameSir equipment to the next level. Get access to advanced options and more precise control as you reset buttons, assign macros, customized equipment lighting and more.



<https://gamesir.hk/pages/g-crux>
(GameSir G-Crux)



<https://gamesir.hk/pages/gamesir-world-app>
(GameSir World App)

 Note: Fully charge GameSir i3 before the first use.

PACKAGE CONTENTS

GameSir G5 Gaming Controller
Micro USB Cable
User Manual

SYSTEM REQUIREMENTS

iOS 9.0 or later
Android 8.0 or later




REGISTRATION

Register your GameSir ID online at <https://gamesir.hk/> to get real-time information on your product's warranty status and a series of exclusive benefits from GameSir.

YOUR BENEFITS

- * 12-month replacement of the same model from the date you received it.
- * Contact us for free online technical support
Website: <https://gamesir.hk>
E-mail: cs@gamesir.hk
Hotline: +1-888-937-1733 (USA & Canada)
Service Hours: Sat.-Sun. 9:00 AM-6:00 PM PST
Mon.-Wed. 6:00 AM-6:00 PM PST
Thur.-Fri. 6:00 AM-3:00 PM PST

DEVICE LAYOUT



- | | |
|--------------------------------|-----------------------------------|
| A Smartphone Stand | M ABXY Trackpad |
| B Mode Indicator Lights | N L5 Button |
| C Power Button | O R5 Button |
| D Mode Button | P L4 Button |
| E SELECT Button | Q R4 Button |
| F START Button | R R2 Button |
| G Left Joystick | S R1 Button |
| H D-Pad | T USB Charging Port |
| I HOME Button | U L1 Button |
| J TURBO Button | V L2 Button |
| K Function Button | W 2.4GHz USB Port |
| L Function Button | X Micro USB Charging Cable |

TURN ON / OFF





- Turn on: Long press "HOME" button for 2 seconds to turn on the gamepad.
- Turn off: Long press "HOME" button for 2 seconds to turn off the gamepad.

LOW BATTERY INDICATOR

- When usable power is lower than 10%, HOME button turns red and flashes slowly. Please charge the gamepad timely.
 - When usable power is lower than 5%, the gamepad will turn off automatically.
- * HOME button flashes slowly in green when charging. HOME button keeps in solid green when fully charged.

CHECK THE POWER

Quickly click POWER button to see indicator lights showing remain power. They recover to original status after showing power for 3 seconds continuously. Indicator lights instruction:

Indicator Light(s)	Power
	75%-100%
	50%-75%
	25%-50%
	1%-25%

AUTOMATIC TURNING OFF

- When the gamepad is on, it will turn off automatically when there is no connection for 2 minutes;
- When the gamepad is connected, it will turn off automatically when there is no operation for 5 minutes;

CONNECTION(iOS)


Step 1

Scan the QR code and download the GameSir G-Crux App for iOS.

Step 2

Turn on the Bluetooth on mobile phone.

Step 3

- For 12.2 or above: Press 2+ Power button to turn on G5 gamepad, the logo indicator light flashes purple .
For 12.2 or below: Press 3+ Power button to turn on G5 gamepad, the logo indicator light flashes pink .
- Open GameSir G-Crux app, select <G5> on the <Device> page, click <Connect>, the logo indicator light will stay on after the connection is successful.

Step 4

Open GameSir G-Crux app, select <G-Touch> and add the game button configuration, save it and start the game.



GameSir G-Crux App (for iOS)



G5 Tutorial for iOS

CONNECTION(ANDROID)

Step 1

Scan the QR code and download the GameSir World App for Android

Step 2

Turn on the Bluetooth on mobile phone.

Step 3

- Press 1 + Power button to turn on G5 gamepad, the logo indicator light flashes yellow 🟡.
- Open GameSir World app, select <Connect> option to connect, and the logo indicator light will stay after the connection is successful.

Step 4

Open GameSir World app, find and add the game, click the game icon to pop up the start option, select <G-Engine Start> to start the game.



GameSir World App (for Android)



G5 Tutorial for Android

日本語

▲ ご注意：最初に使用する前に、GameSir G5 コントローラーを完全に充電してください。

パッケージ内容

GameSir G5 コントローラー
Micro-USBケーブル
取扱説明書

システム要件

iOS 9.0 (以降)
Android 8.0 (以降)




ユーザー登録

<https://gamesir.hk/>にてGameSir IDを作成して、ご購入の製品を登録すると、当製品の品質保証の状態に関するリアルタイム情報と、GameSir会員専用のメリットを得ることができます。

登録による特典

12か月のメーカー限定保証
<https://gamesir.hk/>でのマニュアルの閲覧と無料オンラインテクニカルサポート (英語/日本語対応)
サポートメールアドレス: support_jp@gamesir.hk

各部の名称



- | | |
|--------------------|---------------------------|
| A スマホスタンド | M タッチパッド |
| B モード/電量ライト | N L5 ボタン |
| C 電量チェックボタン | O R5 ボタン |
| D モードボタン | P L4 ボタン |
| E SELECTボタン | Q R4 ボタン |
| F STARTボタン | R R2 ボタン |
| G 左ジョイスティック | S R1 ボタン |
| H 方向キー | T Micro-USB端子 |
| I HOME ボタン | U L1 ボタン |
| J TURBO ボタン | V L2 ボタン |
| K カスタマイズボタン | W 2.4GHz USB 端子 |
| L カスタマイズボタン | X Micro-USB 充電ケーブル |

機能説明

iOSデバイスへの接続

- QRコードをスキャンしてG-Cruxアプリをインストールしてください。
- デバイスのBluetoothをオンにしてください。「設定>Bluetooth」
- iOSバージョンが12.2以降の場合は、2+HOMEボタンを押してGameSir G5コントローラーをオンにします。
同時にHOMEボタンライトがパープル(紫)に点滅します。
iOSバージョンが12.2以下の場合は、3+HOMEボタンを押してGameSir G5コントローラーをオンにします。
同時にHOMEボタンライトがピンクに点滅します。
- 「G-Crux>デバイス管理>GameSir G5」を選択して接続してください。
HOMEボタンライトが青色に点灯すると、接続成功です。
* 「G-Cruxアプリ>G-Crux」で対応ゲームのボタン配置を設定すると、準備完了です。



G-Cruxアプリをインストール



GameSir G5の使い方(iOS)

Androidデバイスへの接続

- QRコードをスキャンしてGameSir Worldアプリをインストールしてください。
- デバイスのBluetoothをオンにしてください。
- 1+HOMEボタンを押してGameSir G5コントローラーをオンにします。
同時にHOMEボタンライトが黄色に点滅します。
- 「GameSir World>GameSir Spirit>CONNECT」をタップして、GameSir G5コントローラーと接続してください。
HOMEボタンライトが青色に点灯すると、接続成功です。



GameSir Worldアプリをインストール



GameSir G5の使い方(Android)

シャットダウン

HOMEボタンを2秒長押しするとシャットダウンします。

自動休眠


GameSir G5 コントローラーが接続済みの状態で300秒以上操作されないと自動的に休眠します。

GameSir G5 コントローラーが接続なしの状態(接続待ち)で120秒以上接続されないと自動的に休眠します。

自動的に休眠したら、もう一度オンにして接続してください。

バッテリー残量説明

GameSir G5コントローラーがオン状態で、電量チェックボタンを押して、現在の残量情報を表示します。

モード/電量ライト	説明
	バッテリー残量:75%-100%
	バッテリー残量:50%-75%
	バッテリー残量:25%-50%
	バッテリー残量:1%-25%

バッテリー残量は10%に下回る場合は、HOMEボタンライトが赤くⓂ️点滅します。バッテリー残量は5%に下回る場合、自動的に低電量保護状態に入ってジャットダウンします。

充電

* 充電時間: 2.5-3.5時間。

充電アダプタ: 5V --- 1A

GameSir G5コントローラーが充電状態ではHOMEボタンライトが緑色で点滅Ⓜ️します。

GameSir G5コントローラーが充電状態ではHOMEボタンライトが緑色で点灯 Ⓜ️します。

简体中文




包装内容

盖世小鸡G5游戏手柄
Micro-USB 充电数据线
使用说明书
合格证

系统要求

iOS (9.0以上)
安卓 (8.0以上)

设备布局



- | | |
|----------------------|------------------------|
| A 手机支架 | M ABXY 触摸板 |
| B 模式指示灯 | N L5 按键 |
| C Power 按键 | O R5 按键 |
| D Mode 按键 | P L4 按键 |
| E SELECT 按键 | Q R4 按键 |
| F START 按键 | R R2 按键 |
| G 左摇杆 | S R1 按键 |
| H 十字键 | T USB 充电口 |
| I HOME 按键 | U L1 按键 |
| J TURBO 按键 | V L2 按键 |
| K Function 按键 | W 2.4GHz USB 端口 |
| L Function 按键 | X Micro USB 数据线 |

第一步 扫描二维码 下载对应APP

安卓用户



下载并安装小鸡游戏世界

iOS用户



下载并安装小鸡助手

第二步 手柄开机，蓝牙连接手机

- 打开手机蓝牙。
 - 安卓用户 按下“①+电源键”组合键开机，LOGO指示灯 ⦿ ：黄灯闪烁。打开“小鸡游戏世界”APP，找到“连接设备”选项进行连接，连接成功后LOGO指示灯常亮。
 - iOS系统12.2以上用户：按下“②+电源键”组合键开机，LOGO指示灯 ⦿ ：紫灯闪烁。
iOS系统12.2以下用户：按下“③+电源键”组合键开机，LOGO指示灯 ⦿ ：粉灯闪烁。
- 打开“小鸡助手”APP，在“设备”页面找到并选择“G5”手柄，点击立即连接，连接成功后LOGO指示灯变为常亮。

第三步 启动游戏

- 安卓用户： 打开小鸡游戏世界APP，找到并添加游戏后，点击游戏图标弹出启动选项，选择“G-Touch直连”，即可进入游戏。
- iOS用户： 打开小鸡助手APP，找到“G-Touch”并添加游戏按键配置，保存后即可进入游戏。

开机/关机

开机： 长按“HOME”键2秒，即可启动手柄。

关机： 长按“HOME”键2秒，即可关闭手柄。

低电量提示

- 当可用电量低于10%时，HOME灯红灯 ⦿ ：慢闪，请及时给手柄充电。
 - 当可用电量低于电池保护电压或低于5%时，手柄自动关机。
- 注意： 本手柄充电时间为 $3\text{H}\pm 0.5\text{H}$ ，充电时HOME键为绿灯慢闪，充电结束（充满）时HOME灯绿灯 ⦿ 常亮

查看电量

快按POWER键，状态灯组显示为当前剩余电量，持续显示3s后恢复原状态灯状态。

模式指示灯	说明
	电量：75%-100%
	电量：50%-75%
	电量：25%-50%
	电量：1%-25%

自动关机

- 手柄开机后在无线连接状态2分钟后将自动关机。
- 手柄连接后，5分钟无任何按键动作会自动关机。

《和平精英》官方直连以及其他官方合作游戏

- 按下“④+电源键”组合键开机，LOGO指示灯蓝灯闪烁。
- 进入游戏，找到游戏设置里面的“连接外设”即可直连直玩。

▲ NOTICE: Please read this Precautions carefully.

- CONTAINS SMALL PARTS. Keep out of reach of children under the age of 3. Seek immediate medical attention if swallowed or inhaled.
- DO NOT use the product near fire.
- DO NOT expose to direct sunlight or high temperatures.
- DO NOT leave the product in a humid or dusty environment.
- DO NOT impact the product or cause it to fall due to strong impact.
- DO NOT touch USB port directly or it might cause malfunctions.
- DO NOT strongly bend or pull cable parts.
- Use a soft, dry cloth while cleaning.
- DO NOT use chemicals such as gasoline or thinner.
- DO NOT disassemble, repair or modify.
- DO NOT use for purposes other than its original purpose. We are NOT responsible for accidents or damage when used for non-original purposes.
- DO NOT look directly at the optical light. It might damage your eyes.
- If you have any quality concerns or suggestions, please contact GameSir or your local distributor.

▲ ご注意:保護者の方へ必ずお読みください。

- 小さいな部品がありますので3歳未満のお子様には絶対に与えないでください。
- 乳幼児の手の届くところに置かないでください。万一飲み込んだ場合は、すぐに医師に相談してください。
- 火気のある場所では絶対に使用しないでください。
- 長時間直射日光当てたり、高温となる場所に置かないでください。
- 本品を湿気やホコリの多いところに置かないでください。
- 本品に物を当てたり、落下させるような強い衝撃を与えないでください。
- 故障の原因になりますので、USB端子を直接手で触ないでください。
- ケーブル部を強く曲げたり引つ張ったりしないでください。
- お手入れの際には、乾いた柔らかい布を使用してください。
- ベンジン、シンナーなどの薬品は使用しないでください。
- 分解や修理、改造は絶対にしないでください。
- 本来の目的以外には使用しないでください。本来の目的以外に使用した場合の事故や損害に対し、弊社は一切その責任を負いません。
- 光学式ライトの光を直接見ないでください。強い光より、目を痛める可能性があります。

* 品質上の問題または提案がある場合に販売元またはアフターサービス担当者に連絡してください。

▲ 注意事項

1. 若商品有质量问题，请首先联系我们的客服进行登记。

联系方式:

QQ: 800082537

电话: 400-8828035(时间: 9:00-18:00)

官网: www.xiaoji.com

出品: 广州小鸡快跑网络科技有限公司

地址: 广州市天河区建业路华翠街68号301A-1

2. 如退货、换商品，请确保商品完好无损(包括商品外包装、附赠品、说明书、售后卡、标签等)，不影响二次销售。
3. 如要保修商品，请务必完整填写用户姓名、联系电话、联系地址，正确填写售后要求与详细说明售后原因，将售后卡随货寄回(如不完整填写保修卡信息，恕无法提供任何售后服务)。

保修卡

(售后政策：非人为损坏，3个月包换、1年保修)

用户姓名	
联系电话	
联系地址	
售后要求	<input type="checkbox"/> 退 <input type="checkbox"/> 换 <input type="checkbox"/> 保修
售后原因	
订单编号	
(注：非小鸡官网途径购买的产品，售后问题请直接与购买商家联系)	

