



GameSir • Gaming is Winning.™

© 2019 GameSir Inc. All rights reserved.
Product may vary slightly from those pictures.

GameSir T6

Bluetooth Controller

User Manual ►

POWER UP YOUR GAMESIR DEVICE



<https://gamesir.hk/>

We hope this manual answering any questions you may have had.
If you have any further questions, please contact us:

GameSir Facebook: <https://www.facebook.com/myGamesir>

Twitter: <https://twitter.com/mygamesir>

Customer Service: cs@gamesir.hk

PACKAGE CONTENTS

GameSir T6 Bluetooth Controller
Micro-USB charging cable
User Manual

SYSTEM REQUIREMENT

iOS 11.0 (or higher)

REGISTRATION

Register your GameSir ID online at <https://gamesir.hk/> to get real-time information on your product's warranty status and a series of exclusive benefits from GameSir.

YOUR BENEFITS

* 12-month replacement of the same model from the date you received it.

* Contact us for free online technical support

Website: <https://gamesir.hk>

E-mail: cs@gamesir.hk




Hotline: +1-888-937-1733 (USA & Canada)

Service Hours: Sat.-Sun. 9:00 AM-6:00 PM PST

Mon.-Wed. 6:00 AM-6:00 PM PST

Thur.-Fri. 6:00 AM-3:00 PM PST

DEVICE LAYOUT



- | | | |
|------------------------------|--------------------|-----------------------------------|
| A Joystick | B A Button | C B Button |
| D LED Indicator Light | E LT Button | F LB Button |
| G Power Button | H Micro-USB | I Micro-USB charging cable |

CONNECT GAMESIR T6 TO THE IPHONE

Step 1

Scan the QRB below , then download and install Geekgamer from App Store.



Step 2

Connect GameSir T6 to the iPhone via Bluetooth

Press and hold the button B of the controller and switch it on at the same time, the indicator light will flash in blue; turn on Bluetooth in the iPhone, then search and pair with GameSir-T6. If the connection indicator light stays blue, the pairing is completed.

Step 3

Add and edit game settings

- Open Geekgamer, select <Add Game>, then select the corresponding game configuration, add and enter<Editor config> .
- Add the background image of button mapping, then adjust the button mapping in the background.
- Press and hold the blank area to add a virtual button. After the addition is successful, a circular icon with <?> pops up, then you can drag it and adjust its position . Press the button of the controller that needs to trigger the virtual button, then the <?> will become the corresponding button. After the setting is completed, save and close. You can start the game now.
- Double click the virtual button to enter the <Key property setting>, you can adjust the Basic mode, MOBA custom and Macro define.

FORCED CLEAR PAIRING

- a. Forced clear the combination button: in the switch-on state, press and hold button A +B+ LT for 3 seconds at the same time, the blue light flashes quickly.
- b. Enter the forced pairing mode : forcibly disconnect the currently connected device, close the gamepad, then press the corresponding mode combination button to power on, wait for other devices to connect.

JOYSTICK CORRECTION

In the power-on state, press button A+LB for 3 seconds at the same time to enter the joystick correction mode. Then the indicator light stays purple. Rotate the joystick to the outermost edge for 3-5 turns and then release it, waiting for 1- 2 seconds. If the correction is successful, the purple light flashes slowly at this time, then press button A to exit the correction mode. The indicator light returns to the same state as before the joystick is corrected.

CHARGING

When charging in the power-on state, the indicator light flashes in red + current status light.

When the battery is full, the indicator light stays red + current status light.

When charging in the power-off state, the indicator light flashes in red, and when the battery is full, the indicator stays red.

When the power is below the battery low voltage alarm , the indicator light flashes in red quickly.

Charging time : 2 - 2.5 Hours.

AUTOMATIC POWER-OFF

The controller is in the connected state, and if without any operation over 5 minutes it will power off automatically.

The controller is not connected over 2 minutes when it is power-on, and it will automatically power off.

When the power is below the battery low voltage alarm , the controller will automatically power off.

AUTOMATIC SLEEP

The controller is in the connected state, if there is no operation for over 5 minutes, it will automatically sleep. In the automatic sleep, press any button of A, B, LT, LB to wake up.

简体中文

包装内容

盖世小鸡T6手游单手手柄

Micro-USB 充电数据线



使用说明书

合格证

系统要求

苹果 (iOS11以上)

设备布局



- | | | |
|--------------|-----------------|----------------------|
| A 摇杆 | D LED指示灯 | G 开关键 |
| B A按键 | E LT按键 | H Micro-USB接口 |
| C B按键 | F LB按键 | I 数据线 |

连接方法

第一步 扫描下方二维码 前往APP STORE下载并安装“智游精灵”。



第二步 蓝牙连接手柄

长按手柄上的“B”键不放，再将手柄上的拨动开关拨动到ON一侧，连接指示灯蓝灯闪烁打开手机蓝牙，搜索到 GameSir-T6游戏手柄，点击并配对，配对成功后蓝灯常亮。

第三步 添加与编辑游戏配置，进入游戏

- 打开“智游精灵”，选择“添加游戏”，找到对应的游戏配置，添加并进入编辑配置界面。
- 添加游戏键位设置背景图，即可在截图上调整键位。
- 长按空白处添加虚拟按钮，添加成功后出现带有“?”的圆形图标，可以拖动调整位置，按下手柄上需要触发该虚拟按钮的按键，设置完成后，点击关闭并保存配置。即可启动游戏。
- 双击虚拟按钮，进入“按键属性设置”，可调整按键模式，连发速率及宏定义等。

强制清空配对记录

- 强制清空组合键：在开机状态下，同时长按“A+B+LT”3秒，此时蓝灯快闪。
- 进入强制配对模式(即强制断开当前已连接设备，关闭手柄，按对应模式组合键开机，等待其他设备连接)。

摇杆校正

在开机状态下，同时按压“A+LB”3秒，进入摇杆校正模式，此时紫灯常亮。转动摇杆至最大外边3~5圈后松开，等待1至2秒，若校正成功，此时紫灯慢闪，再按A键退出校正模式。指示灯恢复至摇杆校正前状态。

电池充电

- 开机状态充电时，指示灯为红灯闪烁+当前状态灯，充满后，指示灯为红灯常亮+当前状态灯。
- 关机状态充电时，指示灯为红灯闪烁，充满后红灯常亮。
- 当可用电量低于低电警报电压时，指示灯红灯快闪。
- 充电时长2至2.5小时。

自动关机

手柄在已连接状态，若无操作超过5分钟，自动关机。
手柄在开机状态下2分钟无连接，自动关机。
当可用电量低于电池保护电压时，手柄自动关机。

自动待机

手柄在已连接状态，若无操作超过5分钟，自动休眠，自动休眠后按A,B,LT,LB其中任意一键唤醒。

⚠ NOTICE Please read this Precautions carefully.

- CONTAINS SMALL PARTS. Keep out of reach of children under the age of 3.
Seek immediate medical attention if swallowed or inhaled.
- DO NOT use the product near fire.
- DO NOT expose to direct sunlight or high temperatures.
- DO NOT leave the product in a humid or dusty environment.
- DO NOT impact the product or cause it to fall due to strong impact.
- DO NOT touch USB port directly or it might cause malfunctions.
- DO NOT strongly bend or pull cable parts.
- Use a soft, dry cloth while cleaning.
- DO NOT use chemicals such as gasoline or thinner.
- DO NOT disassemble, repair or modify.
- DO NOT use for purposes other than its original purpose. We are NOT responsible for accidents or damage when used for non-original purposes.
- DO NOT look directly at the optical light. It might damage your eyes.
- If you have any quality concerns or suggestions, please contact GameSir or your local distributor.

⚠ 注意事项

1. 若商品有质量问题，请首先联系我们的客服进行登记。

联系方式:

QQ: 800082537

电话: 400-8828035 (时间: 9: 00-18: 00)

官网: www.xiaoji.com

出品: 广州小鸡快跑网络科技有限公司

地址: 广州市天河区建业路华翠街68号301A-1

2. 如需退、换商品，请确保商品完好无损（包括商品外包装、附赠品、说明书、售后卡、标签等），不影响二次销售。
3. 如要保修商品，请务必完整填写用户姓名、联系电话、联系地址，正确填写售后要求与详细说明售后原因，将售后卡随货寄回（如不完整填写保修卡信息，恕无法提供任何售后服务。）

保修卡

(售后政策：非人为损坏，3个月包换、1年保修)

用户姓名	
联系电话	
联系地址	
售后要求	<input type="checkbox"/> 退 <input type="checkbox"/> 换 <input type="checkbox"/> 保修
售后原因	
订单编号	
(注：非小鸡官网途径购买的产品，售后问题请直接与购买商家联系)	

