

VICTROLA

Bluetooth Gramophone

Model: VSG-140



BC

Instruction Manual

PLEASE READ THIS INSTRUCTION MANUAL CAREFULLY BEFORE USE
AND KEEP IT FOR FUTURE REFERENCE.

SPECIFICATIONS

BATTERY	Built-In Lithium Battery, 4000mAh (29.6Wh)
CHARGING VOLTAGE/CURRENT	18V ± 0.25V / 1.66A
CHARGING TIME	5 ~ 6 Hrs
PLAYING TIME	8 ~ 10 Hrs
SOUND TRACK	Dual Track
BLUETOOTH RANGE	33ft (10m)
SIGNAL TO NOISE	≥ 80dB
FREQUENCY RANGE	180Hz-20KHz
DISTORTION THD	≤ 1%
MATERIAL	ABS + Fabric
WORKING TEMPERATURE	Temp.: 32°F (0°C) ~ 104°F (40°C) Humidity: 0% ~ 86% RH
STORAGE CONDITION	Temp.: -22°F (-30°C) ~ 140°F (60°C) Humidity: 0% ~ 90% RH
SPEAKER	25W=15Wx1+5Wx2
WEIGHT	5lbs (2100g)
DIMENSIONS	L: 10" (255mm) W: 6" (160mm) H: 13" (340mm)
ACCESSORIES INCLUDED	<ul style="list-style-type: none">• Bluetooth Speaker• Instruction Manual• DC Adaptor• AUX 3.5mm Cable

Please note: As a result of continual improvements, the design and specifications of this product are subject to change without notice.

Bluetooth is a registered trademark of Bluetooth SIG, Inc.
Other trademarks and trade names are those of their respective owners.


Made in China.

SAFETY INSTRUCTIONS

Please be sure to read the following instructions before using the Bluetooth speaker:

1. Keep the speaker dry and do not use near water to avoid the damage of the product's internal circuit.
2. Keep the product away from direct sunlight and extremely high temperatures. High temperatures will shorten the life of the electronic device, destroy the battery and/or distort certain plastic parts.
3. Do not expose the product to extremely low temperatures, it may cause damage to the internal circuit.
4. Do not try to disassemble the product as it may get damaged if you are not a professional.
5. Do not use intensive chemical products or detergent to clean the product.
6. Do not scratch the surface of the product with any sharp objects.

FUNCTIONS



1 AUX-IN Connection

2 Charging Port

3 Touch Screen *Middle Circle*

- Tap Once to Play/Pause/Hang Up
- Tap Once to Answer Phone Call
- Tap and Hold for 3 Seconds to Reject Phone Call. If held too long, Green LED will flash indicating re-pairing is required.

4 Rotary Volume

- Rotate Clockwise to Increase Volume

- Rotate Counterclockwise to Decrease Volume

5 Power Button

- Press and Hold to Power On/Off

6 Touch Screen Circles

- Touch and Slide to the Right From Outer Most Circle to Inner Most Circle to Skip Track (Vice Versa to go to a Previous Track).

7 LED Charging Indicator

- Illuminates Red When Speaker is Charging.

CHARGING

1. Connect the DC Adaptor into the charging port and then plug the Adaptor into a wall outlet.
2. The LED Charging Indicator will illuminate Red to indicate the speaker is charging. The LED Charging Indicator will no longer be Red once charging is complete (5~6 hours).

CAUTION:

The built-in rechargeable battery is not replaceable. Do not remove or replace it, do not throw in the trash or in a fire. Do not dispose device in standard garbage disposal sites. Dispose of device at available Battery Recycling Sites after fully discharging battery. Not doing so may violate local disposal laws and regulations. Please refer to local regulations for proper battery disposal.

OPERATIONS

BLUETOOTH OPERATION:

1. Press and hold the power button until then the LED lights are flashing green and there is an audible sound to indicate the speaker is now in Bluetooth Pairing Mode.
2. Make sure your device's Bluetooth is activated and go to your device's Bluetooth Settings Menu. Select "**VSG-140**" from the Bluetooth Settings Menu to pair your device.
Note: If your phone asks for connecting code, please enter "0000" and confirm it.
3. After successful pairing, the speaker will make a prompt sound and the LED lights will stop flashing and stay green.

NOTE: Connecting time is varied with different mobile phones. If you have connected a device once, the speaker will remember and auto connect to your paired device whenever they are both powered on.

OPERATIONS CONTINUED

AUX-IN OPERATION:

1. Connect the 3.5mm AUX-IN Cable into the AUX-IN port on the bottom of the speaker and into your device's AUX-IN port.
NOTE: If the AUX-IN Cord is connected, the speaker will automatically be in AUX-IN Mode.
2. Press and hold the speaker's power button.
3. The LED lights will illuminate white and then you can control your music from your device.

NOTE: While using AUX-IN, you can only control music functions (play/pause, skip, previous, etc.) directly from your device and not from the speaker.

TWIN PAIRING OPERATION:

If you purchase an additional Bluetooth Gramophone, you may pair them together for optimal stereo sound by following these steps:

1. Make sure your device is not connected to either speaker. Turn on both speakers. Then press the power button on each speaker twice, the LED will illuminate on both speakers, flash green and make an audible noise.
2. Wait a few seconds until the speakers prompt another audible high pitched beep and the green light stops flashing, indicating the speakers are now paired together.
3. After pairing the speakers together, on one speaker tap and hold the green LED until the green light flashes. You may now select "**VSG-140**" from your device's Bluetooth Settings Menu and your music will play from both speakers.

TROUBLESHOOTING GUIDE

The unit does not work.

Fully charge the speaker.
Make sure the speaker is powered on.

No sound from speaker.

Turn up the volume of the connected device and/or speaker.
Disconnect your device, and reconnect.

Bluetooth not connected / sound is distorted.

Enable Bluetooth pairing mode on your device and/or the speaker.
Make sure your device and speaker are within Bluetooth range (33 ft, 10m).
Disconnect AUX-IN Cord if it is connected to the speaker.

Sound is distorted while using AUX-IN.

Make sure the AUX-IN Cord is connected firmly into both the speaker and your device.

Speaker will not answer calls when connected to device.

Ensure your Bluetooth device supports A2DP and HSF (hands-free) profile.

Speakers will not pair together (if additional speaker was purchased).

Make sure your device is not connected to the speaker before allowing speakers to connect to each other. The speakers must pair together first.

IMPORTANT INFORMATION

CALIFORNIA PROP 65 WARNING

"WARNING" This product contains chemicals known to the State of California to cause birth defects or other reproductive harm. For more information on these regulations and a list of chemicals, log on the following website address: <http://www.oehha.ca.gov/prop65.html>

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

INDUSTRY CANADA

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

WARRANTY

Victrola is a registered trademark of Innovative Technology Electronics LLC.

Innovative Technology Electronics LLC.

Limited Warranty: 90 Days Labor, One Year Parts

Innovative Technology Electronics LLC. (IT) warrants the product to be free from "Defects" in materials under normal use for a period of "One Year" from the date of the original purchase. The Warranty is "Not" transferable. IT agrees, within the initial "90 Day" period, to repair or replace the product if it is determined to be defective at "No Charge". It is further agreed that IT will cover the cost to repair or replace damaged "Parts" only for a total period of "One Year" from the date of the original purchase. The warranty does not cover cosmetic damage, antennas, AC cords, cabinets, headbands, ear-pads, or damage due to line power surges, connection to improper voltage supply or settings, misuse, mishandling, accident, acts of God or attempted repair by an unauthorized service agent.

To obtain service, the purchaser MUST present an original sales receipt / proof of purchase. Please contact us at www.ithomeproducts.com to request an RMA (Return Material Authorization) number to return products for service or replacement. Returns without an RMA number on the package will be refused and returned to sender. Upon receipt of the returning item and our full inspection (IT) may issue a replacement to customer for the same item or of one that has equivalent value and features. To return an item, supply full name, return address, phone number, item purchased, receipt of purchase and reason for return to obtain RMA number.

All returns must be in the original packaging or reasonable substitute to prevent damage. Customer "Must" include full name, shipping address and telephone number inside of package. No return will be shipped back to a PO Box or APO address.

Please include your check or money order in the amount of:

- **USD \$5.00 for items \$10.00 to \$39.99 (Price Paid Per Unit)**
- **USD \$10.00 for items \$40.00 to \$99.99. (Price Paid Per Unit)**
- **USD \$16.00, for items \$100.00 and up. (Price Paid Per Unit)**
- **Shipping fees are non-refundable**

to be payable to Innovative Technology Electronics LLC. (for handling and return shipping charges) (IT) will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any / all of the necessary information. Send all inquiries or RMA request via our website

www.ithomeproducts.com/support.

Innovative Technology Electronics LLC.

1 Channel Drive

Port Washington, NY 11050

Toll free: 1-877-483-2497

Website for support: www.ithomeproducts.com/support

There are no express warranties except as listed above.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CUSTOMER, (IT) SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.