


SD90

50Hz 949-0526-07
60Hz 949-0526-06
50Hz 949-0586-02
Tri. 50Hz 949-0526-85 AEG
60Hz 949-0526-03



SD90

949-0837-72



949-0755-08


949-0734-54

949-0525-39

949-0525-41

949-0525-40

949-0525-75




949-0525-41

949-0525-40


949-0525-13



949-0525-72




949-0525-73



949-0525-10



949-0525-71



949-0755-09

949-0525-70

949-0525-08



0710-50

949-0831-30

949-0711-61

949-0821-05

949-0526-77

32-90

949-0525-69


949-0734-54

949-0755-08

949-0755-08

949-0734-54

949-0790-30




949-0836-45



949-0525-72

949-0710-40

949-0534-74



949-0839-46



949-0530-40



949-0836-45

949-0710-40

949-0836-53



949-0821-05

949-0526-77

949-0525-69

949-0734-54

949-0755-08

949-0839-46

949-0530-40

949-0790-30

949-0839-46

949-0530-40

949-0790-30

949-0839-46

949-0530-40

949-0790-30

949-0839-46

949-0530-40

949-0790-30

949-0839-46

949-0530-40

949-0790-30

949-0839-46

949-0530-40

949-0790-30

949-0839-46

949-0530-40

949-0790-30

949-0839-46

949-0530-40

949-0790-30

949-0839-46

949-0530-40

949-0790-30

949-0839-46


949-0530-40

949-0790-30


949-0839-46

949-0530-40

949-0790-30



B



A

FIGURE 04
ADJUSTEMENT OF ANTI-SUCKBACK VALVE ASSY. (see 3.3.4.)