

5945 Daley St, Goleta CA 93117

www.cmtopline.com

info@cmtopline.com

1.800.827.1333



ROTARY TUMBLER BASES

BASIC OPERATING INSTRUCTIONS

This machine has been tested and pre-run at the factory

CAUTION - Always make sure the power cord is plugged into a *grounded* outlet. Make sure the area around the machine is dry.

This machine is designed only to be used on a solid surface. The unit must be level. If not level the barrels while revolving will move to one to one side rubbing against the bearing assembly.

General Cleaning exterior:

The fiberglass base can be cleaned by wiping them with a damp cloth. Be careful not to get any moisture around the switch or electrical cord. The fiberglass is Impervious to chemicals. The Shaft(s) have a neoprene cover that can be cleaned by wiping them with a damp cloth.

Motor and Bearings:

The tumbler motors are "designed for continuous use" and never need oiling. No lubrication is required for bearings or shafts.

Variable Speed Machines:

If a variable speed machine was purchased please refer to the **KB Controller Quick Start Guide** included with the machine.