

Battery Replacement Instructions



Airplane and Flower

Instructions

1. Use a small screwdriver to loosen and remove the safety screw on the underside of the light's clip.
2. Using your thumb, slide the cover in the direction of the arrow.
3. Insert the batteries according to the (+/-) markings and replace the cover and screw.