



DuoFlex

LED Music Light Kit

User Guide

Read all instructions prior to using your new product.

USING YOUR DUOFLEX LED MUSIC LIGHT KIT:

- Turn on the light by pressing the on/off buttons located on each light head. Pressing the buttons again will cycle through each light head's three brightness settings.
- Your DuoFlex light uses energy efficient LEDs - you'll never need to replace any bulbs.
- Your DuoFlex is powered by 3 AAA batteries (not included), or a micro USB cable (included).
- To replace or insert new batteries, gently slide the battery door toward the bottom of the base and insert 3 AAA batteries using the positive (+) and negative (-) guides imprinted in the battery compartment.

SAFETY INFORMATION:

- This product is not a toy and is not intended for children under 13 years of age.
- Do not stare directly into the LEDs or shine them into the eyes of others.
- Do not attempt to remove or replace the LEDs.
- Improper use of this or any other battery operated product may cause batteries to leak or explode, which may result in chemical burns and/or personal injury.

If any amount of battery leakage comes in contact, directly or indirectly, with skin, eyes, inside of mouth, or anywhere on body: 1) immediately flush the affected area with plenty of cool, running water (do not use hot water). 2) Contact your local doctor, Poison Control Center, or hospital emergency room, or call the 24 hour National Button Battery Ingestion Hotline at: 1-202-625-3333, which accepts collect calls from both the US and Canada. Also, give the hotline number to your doctor or hospital emergency room. If injury appears serious, call: 911.



www.mightybright.com



CUSTOMER SERVICE:

For questions and assistance please contact us at:
800.922.3233 • customerservice@mightybright.com



Visit us at:
www.mightybright.com