



MiniFlex 2

LED Light

User Guide

Read all instructions prior to using your new product.

USING YOUR MINIFLEX 2 LED LIGHT:

- Turn on or off the light by sliding the power switch forward or backward. The sliding switch is located on the top of the light head.
- Your MiniFlex 2 LED light uses energy efficient LEDs which will never need to be replaced.
- MiniFlex 2 is powered by 2 CR2032 batteries, (included).
- To replace or insert new batteries, gently slide the battery door toward the top of the base using the indented circle on the back of the light. Be sure you insert the batteries using the positive (+) and negative (-) guides imprinted inside the battery compartment.

SAFETY INFORMATION:

- This product is not a toy and is not intended for children under 13 years of age.
- Do not stare directly into the LEDs or shine them into the eyes of others.
- Do not attempt to remove or replace the LEDs.
- Improper use of this or any other battery operated product may cause batteries to leak or explode, which may result in chemical burns and/or personal injury.

If any amount of battery leakage comes in contact, directly or indirectly, with skin, eyes, inside of mouth, or anywhere on body: 1) immediately flush the affected area with plenty of cool, running water (do not use hot water). 2) Contact your local doctor, Poison Control Center, or hospital emergency room, or call the 24 hour National Button Battery Ingestion Hotline at: 1-202-625-3333, which accepts collect calls from both the US and Canada. Also, give the hotline number to your doctor or hospital emergency room. If injury appears serious, call: 911.

Flexible neck

Sliding power switch

Two LEDs

Dual-function variable width clip

Battery compartment

CUSTOMER SERVICE:

For questions and assistance please contact us at:
800.922.3233 • customerservice@mightybright.com



Visit us at:
www.mightybright.com