



flexible Silicone neck

power/dimmer
switch

LEDs

clip

micro USB power source



NuFlex User Manual

Read all instructions prior to using your new product.

A few tips to get started:

- Turn on the light by pressing on/off button located on the light head. Pressing the button again will cycle through the light's three brightness settings (High, Med, Low) and eventually cycle off.
- Your NuFlex light uses energy-efficient LEDs - you'll never need to replace any bulbs.
- Your NuFlex is powered by 3 included AAA batteries or a micro USB cable (not included).
- To replace or insert new batteries, gently pull out the battery tray at the base of the light. Insert 3 AAA batteries using the positive (+) and negative (-) guides on the plastic.

Careful!

This product is not a toy and is not intended for children under 13 years of age. Do not stare directly at the LEDs or shine them into the eyes of others. Do not attempt to remove or replace the LEDs. Improper use of this or any battery-operated product may cause batteries to leak or explode, which may result in chemical burns and/or personal injury.

If any amount of battery leakage comes in contact, directly or indirectly, with skin, eyes, inside of mouth or anywhere on body:

1. Immediately flush the affected area with plenty of cool, running water (do not use hot water).
2. Contact your local doctor, Poison Control Center, or hospital emergency room, or call the 24 hour National Button Battery Ingestion Hotline at 1-202-625-3333, which accepts collect calls from both US and Canadian citizens. Also give the hotline number to your doctor or hospital emergency room. If injury appears serious, call "911."

Want to get in touch?

Call us at: 800.922.3233.

Email us at: customerservice@mightybright.com.

Write us at:

Mighty Bright
5540 Ekwil, Suite 130
Santa Barbara, CA 93111

Visit our website at www.mightybright.com.

