



## ATTENTION:

- Please review all the instructions and diagrams carefully before assembling the lamp. This will reduce assembly time and avoid damage.
- Do not force parts. Do not apply excessive force to wires during assembly.
- Remove all the packing materials before use.

## WARNING:

- Do not look directly into the LED's and do not shine them into the eyes of others. As with other high intensity light sources, eye damage may occur.

## ASSEMBLY STEPS

1. Remove the recyclable paper tray from the recyclable carton. Carefully remove the flexible arm with the lamp head from the tray. Gently lay them on a large, clean work surface.
2. Assemble pole with the base flat on the ground. Carefully insert the pole into the base being sure to line up the gray triangular installation marks on the pole and base. (FIG. A)
3. Once secure, gently rest the entire light onto its side. Be careful to protect the lamp head as you set it down.
4. Using the included screw assembly (FIG. A), connect the base to the pole from the bottom of the base, turning clockwise until finger-tight. Do not over-tighten.
5. Plug in the supplied AC adapter to the DC jack on the back of the base. The lamp is now ready for use.
6. Be sure to charge the batteries for 4 full hours before attempting to use without the AC power supply.

## BATTERIES:

- This product comes with built-in rechargeable batteries along with an AC adapter. The light can be used with or without the AC adapter, assuming batteries are charged.
- Battery life ranges from 2.5 hours (highest setting) to 7 hours (lowest setting). Batteries charge fully in 4 hours.

## AC/DC Adapter specs:

- Input : 100-240VAC, 50 – 60 HZ. Output : 12V DC 1.0A. AC/DC jack is located on the back of the lamp base.

## OPERATION

- The power switch is located on the top of the lamp head. Press it once to turn on the light. Press again to cycle through the other brightness levels (High, Med, Low, Off). If the light fails to operate after turning the switch on, check that the batteries have been fully charged or that the AC power supply is fully plugged in.
- The color temperature selector is also located on the top of the lamp head. The touch-activated selector continuously cycles between cool (5,000K) and warm (3,000K) color temperatures. Press and hold the sensor to select the ideal color temperature for your needs.
- The flexible arm is intended as a convenient means of adjusting the lamp. Properly handled it will provide a lifetime of service. Do not abuse the flexible arm by bending it severely, abruptly, or forcefully.
- Do not attempt to remove or replace the LED's.



Visit us at:  
[www.mightybright.com](http://www.mightybright.com)