

 MIGHTY
BRIGHT®

WonderFlex

RECHARGEABLE LED LIGHT



2
LEDS

20
LUMENS

10
HOURS

User Guide

Read all instructions prior to using your new product.

USING YOUR WONDERFLEX LED LIGHT:

- Turn on the light by pressing the on/off button located on the light head. Pressing the button again will cycle through the light's three brightness settings (High, Med, Low) and eventually cycle off.
- Your WonderFlex light uses energy efficient LEDs - you'll never need to replace any bulbs.
- Your WonderFlex can be powered by the included rechargeable batteries, or while connected to the micro included USB cable.
- The rechargeable battery charges fully in 3 hours, and will last for 10 hours on high, and up to 45 hours on low.
- Never remove the rechargeable battery unless you are recycling the product, in which case it can be removed by unscrewing and sliding off the back battery cover.

SAFETY INFORMATION:

- This product is not a toy and is not intended for children under 13 years of age.
- Do not stare directly into the LEDs or shine them into the eyes of others.
- Do not attempt to remove or replace the LEDs.
- Improper use of this or any other battery operated product may cause batteries to leak or explode, which may result in chemical burns and/or personal injury.

If any amount of battery leakage comes in contact, directly or indirectly, with skin, eyes, inside of mouth, or anywhere on body: 1) immediately flush the affected area with plenty of cool, running water (do not use hot water). 2) Contact your local doctor, Poison Control Center, or hospital emergency room, or call the 24 hour National Button Battery Ingestion Hotline at: 1-202-625-3333, which accepts collect calls from both the US and Canada. Also, give the hotline number to your doctor or hospital emergency room. If injury appears serious, call: 911.





CUSTOMER SERVICE:

For questions and assistance please contact us at:
800.922.3233 • customerservice@mightybright.com



Visit us at:
www.mightybright.com

WonderFlex-R REV200