

How to operate your whole house fan

The hardwired switch, wireless remote and web control interface look and operate the same. There are 4 buttons that control the speed, on/off & fan timer functions.



Pressing the SPEED Up button will start the fan on low and then increase the speed incrementally up to the maximum speed (high speed on 2 speed units). Pressing the SPEED Down button will decrease the fan speed incrementally down to the minimum speed (low speed on 2 speed units).

TIMER Operation:

- 1. Turn ON the whole house fan using the SPEED Up button
- 2. Press TIMER button (once for 1 hr, twice for 2 hrs, etc... up to 12 times for 12 hrs)
- 3. Changing the fan speed after setting the timer will not effect the timer setting.
- 4. Fan will turn off after set time. Press OFF at any time to turn the fan off.

Important Operating Tips

- Never operate the fan without opening a window this can create excessive negative pressure in the house.
- Only operate your fan when the outdoor air is cooler than your indoor air.
- Make sure your A/C is off when you run the fan or you'll be blowing expensive conditioned air right out of your house!
- We recommend running your AirScape all night long. Here's why: The goal is to cool your entire house down, not just the air. It takes time to pull the heat out of the Sheetrock, structure and contents of a house. By ventilating all through the night, the house starts the next day thoroughly cooled so you can delay or eliminate running energy consuming air conditioning the next day. AirScape Whole House Fans are very energy efficient so running on low speed through the night costs just pennies.
- Use high speed to quickly cool down the house in the evening and low speed to run quietly through the night.
- You can control where the cooling effect is focused by which windows you open. Just visualize the path the air will take between the open windows and the unit. Generally, the longer the path, the more cooling effect.
- If your home has a basement, extra cooling effect can be achieved by drawing air in through the basement windows.

Please contact AirScape Customer Service at 866.448.4187 or <u>experts@airscapefans.com</u> with any questions.