

How to Change the Minimum Set Temp Thermotec Inverter Heat Pumps

Overview

On the Thermotec Inverter heat pumps, the default lowest set water temperature is +15c On koi ponds, often the owners want to keep the pond at +10 to +12c in winter This guide shows you how to change the lowest set temperature from +15c to +10c

<u>Procedure</u>

At the home screen, press on the cog icon



Enter the access code of 66



Press the right button to scroll through the parameters to parameter R10

| | Sy Sy | stem param | eters |
|-----|-----------|-----------------------|-----------|
| | Parameter | Meaning | Set value |
| | D01 | Start Defrosting Temp | -7.0 °C |
| -le | D01 | Start setp. | 5.5 bar |
| | D02 | End Defrosting Temp | 13.0 °C |
| | D03 | Defrosting Cycle | 45 min |
| | D04 | Max. Duration | 8 min |
| | D06 | Defrost type | Eco. |
| 5 | | | |

Click on the value for **R10** which is normally on 15



Change the value from 15 to 10

Exit back to the home screen

You should now be able to set the desired water temperature to +10c Note: We do not recommend that you set this to lower than +10c

HeatPumps4Pools 2019