

LAURA JAMES

CARE GUIDE CAPRI

HOME - GARDEN - LIFESTYLE

SUNLIGHT AND HEAT

- Avoid exposing your product to excessive heat as this can cause issues with the finish of the product.
- Direct sunlight will cause the colour of the product to change, especially if the furniture is placed near a window. Use in hot and sunny conservatories is not recommended
- At least a 30cm clearance from heat sources such as radiators is advised to prevent colour change or permanent marks from occurring.
- Never place hot dishes or mugs directly on to surfaces, use tablemats or coasters. Prolonged use of hot equipment e.g., a laptop, may cause scorching.



LEGS, ASSEMBLY & MOVING

- The items must be positioned on a level surface to ensure that it does not rock.
- Take care when moving products. We recommend they are lifted by two persons as dragging items across the floor will cause damage to the item.
- As the item is self-assembly, it should be assembled at the intended location and lifted carefully into position.
- From time to time tightening of all fixings may be needed to prevent loosening which can create squeaks and movement, full instructions are enclosed with your product.



MAINTENANCE AND CARE INSTRUCTIONS

CLEANING

- Regularly dust with a soft cloth and occasionally wipe lightly dampened with a mild, bleach-free detergent solution and dry with a lint-free clot.
- Beeswax furniture polish from a reputable supplier may be used, however, the repeated use of a polish containing silicone is not recommended as it will lead to a build-up of a silicone film altering the appearance
- Follow cleaning instructions carefully, spills should be removed immediately by blotting with a dry white cloth, especially fatty or oily substances. If the spillage causes staining or the piece requires routine cleaning, we recommend a specialist cleaner

- product.

CARE

• Do not drop furniture onto corners or feet, this will weaken and damage frames, feet or legs.

 Avoid contact with chemicals such as hair and skin preparations, fake tans, insect repellents and other cosmetics, or household cleaning materials, other than those recommended as these may affect the finish.

• If your furniture becomes stained, scratched, chipped or suffers other damage we recommend professional help is sought to restore it.

Following the guidelines above will ensure product performance is maintained. Laura James is not responsible for defects caused by the misuse of your

email:

Jnit 2 Provincial Park, Nether Lane, Ecclesfield, Sheffield, S35 97X

WHHMM

