

INSTALLATION INSTRUCTIONS FOR ICE MAKER PART NO. 243297606



WARNING! Electrical Shock Hazard

To avoid risk of electrical shock, personal injury or death; disconnect electrical power before servicing.



Tools Needed:

Philips head screwdriver
1/4 inch socket or nut driver

1. Unplug appliance and/or turn off circuit breakers to prevent electrocution.
2. Remove the ice bucket.
3. Remove the ice maker front cover by using a Philips head screwdriver.
4. Use a 1/4" socket or nut driver to remove the screw holding the wire harness cover.
5. Remove the cover and disconnect the wire harness connector.
6. Pull the ice maker towards you to detach it.
7. It is recommended to remove the ice maker housing for easier access to the ice maker. Start by removing the adjacent shelf. Next remove the three screws holding the housing in place, then pull the housing out.
8. Cut any zip tie retainers and remove the old ice maker completely from freezer.
9. Install the new ice maker by feeding the wires through the channel on the ice maker. Secure them with zip ties and trim any excess length of each zip tie. Reinstall the housing by first feeding the ice maker through the rear of the housing. Feed the wires through the hole in the top of the housing. Re-fasten the housing with the three previously removed screws.
10. Replace the adjacent shelf.
11. Align the new ice maker on the mounting stud and push back until it locks into place. Connect the wire connectors.
12. Re-install the wire harness cover using the previously removed screw. Re-install the front cover.
13. Replace the ice bucket and plug in appliance.

