



OPERATING INSTRUCTIONS

P.O Box 68323, Bryanston 2021 200 Cussonia Park, 3 Ridge Road, Laser Park, Honeydew, South Africa Tel: (011) 794-6311 • Fax: (011) 794-6233



HELPFUL HINTS

- Always make sure TENT is dry when stored away from RATS and MICE.
 Do not wash TENT with detergent. ONLY wipe with CLEAN CLOTH.







OPERATING INSTRUCTIONS – TO OPEN




Blade in closed position




Loosen securing latch by Pressing on latch lock.




Guide latch lock through centre hole.




Take Hold of handles and lift in order to open tent.



Tent in open position.



Remove Retractable ladder in bag from tent.




Remove bag from retractable ladder.







OPERATING INSTRUCTIONS




Place ladder into ladder locking plate.




Adjust ladder foot piece to required height by pulling on the rope. Make sure pins are located before climbing up.




Pull on ladder lock straps to extend retractable ladder.



Insert canopy rod into stainless steel insert in tent.




Thread the hook end of canopy rod through eyelet in tent canopy.






BLADE


OPERATING INSTRUCTIONS - TO CLOSE




Clip the elastic cords together again in help with closing of the tent.




There is an elastic cord that helps pull the sides of the tent in to gain easy access to this cord a pull toggle has been attach to it:




Pull on the toggle and move the strap up so as It's in the middle of the fabric in order to pull fabric inwards.




Remove canopy rods.



Remove retractable ladder.



Slide retractable ladder back into the closed position by pulling on ladder locks. Take care not to jam fingers when sliding.




Slide retractable ladder bag over ladder and stow in tent.




BLADE


OPERATING INSTRUCTIONS - TO CLOSE




Pull down on pull strap in order to close tent.




Leaving a window open with the gauze closed helps release trapped air from tent.



Latch lid of tent closed.



Latch lock may require a little guiding in to go through centre hole.




ON THE ROAD AGAIN!! - ENJOY THE RIDE!!




INSTALLATION INSTRUCTIONS

P.O. Box 68323, Bryanston 2021 14 Susan Str. Strydompark. Randburg South Africa Tel: (011) 792-1731 Fax (011) 791-0727



Slide fitting kit plates into tent rails and secure.

PLAN VIEW DART BASE RAIL CENTRES



Internal Light.

If the tent is fitted with an internal light the extension cord should be connected to the tent first in order to prevent a short circuit. If a short circuit has occurred replace 15 Amp inline fuse with a new one.

