

## **X10 KR16A Panic Keychain Remote with One Unit Control Instructions**

### **Activating the KR16A**

- Install 2 AAA batteries being sure to observe the correct polarity.
- After an extended period of time of not having been used without any batteries installed, you may need to “wake up” the remote.
- Press and release the PANIC button on the remote until the LED lights up. You may need to do this up to a dozen times or so.

### **To change the Housecode**

- Press and hold the LIGHTS ON button. The red LED blinks rapidly. About 3 seconds later, the LED blinks the current setting: 1 blink for Housecode A, 2 blinks for B..... 16 blinks for P.
- Release the LIGHTS ON button.
- Press and release the LIGHTS ON button the appropriate number of times for the Housecode you want to control. Once for A, twice for B, etc. The LED blinks for each press. IMPORTANT: Hold the button on your last press. 3 seconds later, the red LED blinks back the new setting.
- Release the LIGHTS ON button. Your KR16A remote is now set to the new housecode.

### **To change the Unit Code**

- Press and hold the LIGHTS OFF button. The red LED blinks rapidly. About 3 seconds later, the LED blinks the current setting: 1 blink for Unit Code 1, 2 blinks for 2..... 16 blinks for 16.
- Release the LIGHTS OFF button.
- Press and release the LIGHTS OFF button the appropriate number of times for the Unit Code you want to control. Once for 1, twice for 2, etc. The LED blinks for each press. IMPORTANT: Hold the button on your last press. 3 seconds later, the red LED blinks back the new setting.
- Release the LIGHTS OFF button. Your KR16A remote is now set to the new unit code.

### **To initialize the remote into your X10 security system**

- Set the slide switch on your security system console to INSTALL.
- Press and hold either the PANIC or STOP buttons until your security console chimes indicating that it has accepted the KR16A.
- Return the INSTALL switch back to RUN. Your panic keychain remote can now be used to set off your security system in an emergency. To set off your security system, press AND hold the PANIC button continuously for about 10 seconds.