
## Wall Receptacle Module, Model SR227

The SR227 Wall Receptacle Module is designed to control unrestricted loads up to 15 Amps. It has two outlets, the upper one is X10 controlled and the lower one is always on. The SR227 does not respond to All Lights On.

### Installation

- Turn the power off at the circuit breaker panel.
- Remove the wall plate and unscrew the old receptacle from its box.



- Disconnect the wiring to the old receptacle.
- Connect the black wire on the SR227 to Live (black wire), connect the white wire on the SR227 to Neutral (white wire), and connect the green wire on the SR227 to ground (or to a metal wall box) using the wire nuts provided. Refer to the diagram above.
- Refit the SR227 in the wall box and finish off with the trim plate provided. Turn the power back on at the circuit breaker panel.

#### Setting up the SR227 Wall Receptacle Module

- Using a small screwdriver, set the black Unit Code dial to an unused code that can be controlled from your X10 Controller(s).
- Set the red House Code dial to the same letter as your X10 controller(s).
- Plug an appliance (or a lamp) into the **top** outlet.

#### Testing the SR227 Wall Receptacle Module

Make sure the lamp/appliance's switch is on. Plug an X10 Controller into the **bottom** outlet. Press the On and Off buttons on the Controller that correspond to the Unit Code setting on the SR227. If the lamp/appliance turns on and off you can unplug the Controller and move it to its permanent location, if it doesn't work, try the Controller in different outlets. You can also cycle the load off then on (local control/sense) to turn the SR227 on.

Trim

## Check Out our Web site at:

# www.x10.com

# For more information on X10 products and special promotional offers.

#### X10 Wireless Technology, Inc. 90 Day Limited Warranty

X10.com, a division of X10 Wireless Technology, Inc. (X10) warrants X10 products to be free from defective material and workmanship for a period of 90 days from the original date of purchase at retail. X10 agrees to repair or replace, at it's sole discretion, a defective X10 product if returned to X10 within the warranty period and with proof of purchase.

If service is required under this warranty:

- 1. Visit www.x10.com/support/return\_policy.htm, or e-mail sales@x10.com to obtain a Return Merchandise Authorization (RMA) number.
- 2. Return the defective unit postage prepaid to X10 (see address on back).
- 3. Enclose a check for \$4.00 to cover postage and handling.
- 4. Enclose a dated proof of purchase.
- 5. X10 is not responsible for shipping damage. Units to be returned should be packed carefully.

Please visit www.x10.com/support for help.

SR227-6/13

Trim

Print reduced by approx 85%. Final size of above = approx. 7 3/4" x 4 3/4" Folds into a sheet 3 7/8' x 2 3/8" (Like all other instruction sheets)

# X10 Wireless Technology, Inc. 400 Forge Way, Suite 409-412, Rockaway, NJ 07866

# RMA#

Tear off and keep the portion to the right (setup instructions are on the other side of it) and keep for future use.

## visit www.x10.com/support/return\_policy.htm or e-mail sales@x10.com to obtain a Return Merchandise Authorization (RMA) number.

Write your RMA number above. Tear off and tape this label to the outside of the package and mail it (postage prepaid).

#### Mini Timer MT13A

A Controller, Timer and Alarm Clock all in one! Programs up to eight X10 Modules to go on and off at specific times, up to a total of 64 timed events. Controls eight modules instantly. Dims lights too.

#### Maxi Controller SC503

Lets you control up to 16 X10 Modules at the touch of a button from anywhere in the house. Dims lights too!

#### **Mini Controller MC10A**

Lets you control up to eight X10 Modules at the touch of a button from anywhere in the house. Dims lights too!

#### 2-Way Home Control Interface CM15A

Set up from a PC to control up to 256 X10 Modules. ActiveHome Pro software download & USB cable included.

#### Thermostat Set-Back TH2807

Automatically sets-back your central heating/air conditioning. Mounts on the wall under your existing thermostat and plugs into an Appliance Module.

#### Wireless Remote Control System RC5000

Lets you control 16X10 modules from inside or outside your home. Can also dim and brighten Lamp Modules and Wall Switch Modules. Works with the HR12A PalmPad Remote and X10RFWallSwitches (SS13A, SS15A).

#### Lamp Module LM465

Can be Dimmed and Brightened from any X10 Controller. Responds to "All lights on". Rated for 300 W. Incandescent only.

2-Way version LM14A.

#### SocketRocket LM15A

Screws in to an existing light fixture. Controls up to 150W, incandescent only.

#### Appliance Module - AM486/AM466

Two pin polarized (AM486) or 3 pin grounded (AM466). For controlling an air conditioner, TV, stereo, etc. anywhere in the home. Rated 15A for heaters, coffee pots etc.; 1/3 H.P. for motors; 400W for TVs; 500W for lamps. 2-Way versions available AM14A (2 pin), AM15A (3 pin).

#### Wall Switch Module WS467

For controlling important indoor and outdoor security lights. Replaces your existing wall switch and installs like a regular dimmer. Dimmed/brightened from any X10 Controller. Rated 500W incandescent only.

#### 3 - Way Wall Switch Module WS4777

For controlling a light which is controlled by two switches. Same features as WS467.

#### Split Receptacle Module SR227

Replaces existing wall outlet. The top outlet functions like an Appliance Module, the bottom one is a regular outlet. Rated 15A.

#### **Universal Module UM506**

Isolated contact relay and beeper. Can be set for momentary or continuous operation. Not compatible with X10 security systems.

Trim