



PROFESSIONAL

BM-LW618N

INSTRUCTIONS MANUAL

PROFESSIONAL SERIES



HEAVY DUTY STAINLESS STEEL **PREP TABLE**

www.tylrhome.com


IMPORTANT REMINDERS

1. Carefully read all instructions before use and save for future reference. Failure to follow all instructions may result in injury and/or damage.
2. The warnings, cautions, and instructions in this manual cannot cover all possible conditions or situations that may occur. The user must always be aware of their environment and ensure that they use the product in a safe and responsible manner.
3. Do NOT modify the product in any way. Unauthorized modification may impair the function and/or safety of the product and may affect the life of the product. Any modifications will void warranty.
4. Check for damaged parts. Before using this product, carefully check that all parts are in good condition, and that the product will operate properly and perform its intended function. Check for damaged parts and any other conditions that may affect the operation of this product. Replace damaged or worn parts, and never use this product with a damaged part.
5. Table must be used with at least one shelf installed for stability.
6. Lock the casters when being used as a work surface.
7. Do NOT overload the product.
8. Do NOT roll the product on an uneven surface. Only move the product on a smooth surface. Rolling over rough or

uneven surfaces may cause casters to break or items on the product to fall, resulting in injury and / or damage. Wood and laminate flooring can be scratched or dented. Ensure your flooring can bear the weight of loaded product before rolling loaded product across your flooring.

SAVE THESE INSTRUCTIONS.

PARTS LIST



Item	Description	Qty.
A	Top Table	1
B	Bottom Shelf	1
C	Legs	4
D	Swivel Caster Wheels	4
E	Hex Key	1
F	Hex Screw	16

ASSEMBLY INSTRUCTIONS

1. Lay the table face-down on a smooth, flat surface. You may use any material for padding to avoid scratching the table surface.
2. Insert legs into the round slots on bottom of the top table. Make sure the legs are fully inserted. Fasten the hex screws using the provided hex key.
3. Slide shelf over each leg to desired height.

Using the provided hex key, tighten hex screws into shelf until securely in place.

4. Insert caster wheel into each leg. If the rubber expander is too large for leg tube opening, loosen the top nut by turning it counterclockwise. Once the caster is inserted into the leg, tighten by turning the caster until it is firmly inserted inside the legs.

Make sure to position the locking casters on the same side of the table.

5. Turn the table right-side up.
6. Push down on the brake to lock the caster. Lift up to unlock the caster.



CLEANING AND MAINTENANCE

1. Use a quality stainless steel cleaner and follow instructions that come with the cleaner.
2. Wipe along the grain and not against.
3. Avoid harsh, abrasive cleaners, and other corrosive chemicals.
4. Do not use scouring pads for cleaning.
5. Keep dry and avoid damp environments. Do not leave out unprotected in the elements.