



INSTRUCTIONS

www.NFlightNomad.com

STEP 1

Locate auxiliary audio cable input for your headset.



STEP 2

Attach microphone mounting pad (3M Dual Lock) to earcup near the auxiliary audio cable input.

- a. Clean earcup before attaching mounting pad.
- b. Press and hold mounting pad to earcup for 30 seconds.



STEP 3

Press firmly to attach microphone to mounting pad. 3M Dual Lock will snap together with an audible "click."



STEP 4

Plug microphone cable into auxiliary audio cable input on headset.



STEP 5

When flying, the word "TALK" must be oriented facing toward your mouth in order to pick up your voice clearly.



STEP 6

Adjust headset volume with volume wheels on the in-line control box.



Set switch to **S**tereo or **M**ono based on your aircraft's intercom system.

AUXILIARY AUDIO


Your NFlight Nomad has two auxiliary audio ports. Both ports have identical in-and-out functionality.

- To listen to music, plug the included 3.5mm cable into one of the ports and connect the cable to your music source.
- To connect an optional Bluetooth adapter, plug it into one of the ports.
- If you prefer to wear earbuds rather than a headset, plug them into one of the ports.



REMOVAL

To remove microphone from headset, unplug 2.5mm cable from earcup. Peel microphone away from 3M Dual Lock pad, rather than pulling microphone straight away from headset.



The NFlight Nomad is covered by our lifetime warranty.

For questions or warranty support, please contact Support@NFlightNomad.com