

How to take care for your quartz CUCKOO CLOCK















X



































How to take care of your CUCKOO CLOCK

Cleaning your Cuckoo Clock

To keep your cuckoo clock looking bright and attractive requires only a simple cleaning practice. A soft, dry paintbrush or static dusting cloth will keep dust and dirt build up away.

Please do not use harsh chemicals anywhere on the clock, as it can damage the wood and varnish. Your electric movement **does not** require any internal maintenance.

Batteries and terminals

Only use good quality batteries such as Duracell, as they



will last longer and are the less likely to leak.


In the event that a battery does leak and cause some corrosion, you can carefully remove the residual acid by using a fine sandpaper.

Environmental factors

Environmental factors can affect the way your clock runs and its longevity. Warm or moist air can warp and distort wooden parts, while dust and extreme heat may cause create wear on electrical parts.

It is highly recommended to keep your clock out of areas with high humidity and extreme heat. Therefore, careful consideration must be taken if you wish to hang your clock in kitchens, wet areas and over fireplaces.







CONTACT INFORMATION

Address

50 Main Street

Hahndorf South Australia 5245

Ph: 08 8388 7324 **Email:** info@thegermanvillageshop.com.au Website: www.thegermanvillageshop.com.au



