

TOMO & TOMO II

BY G I D D I



USER GUIDE



TOMO & TOMO II

BY G I D D I

Congratulations on discovering a new pleasure and sexual wellness experience! Before getting started with **TOMO** or **TOMO II**, please take a moment to review this user guide.

Questions or feedback? Contact us at

hello@mygiddi.com

QUICK START

- Charge up to 90 minutes
- Rinse with warm water
- Dry with a lint free cloth or towel
- Use water-based lubricant only

Using Device Without Remote

- Hold **POWER** (⏻) on device to turn on/off
- Press **POWER** (⏻) on device to cycle through come hither motion modes
- Press **VIBRATION** (Ⓜ) on device to cycle through vibration modes

Change Pattern Modes


Turn On/Off



Hold for 3s



Come Hither
Motion Modes



Vibration
Modes




POWER/PULSE



VIBRATE

START HERE




Using Device With Remote


- Hold **POWER** (⏻) on remote to turn on/off
- Press **POWER** (⏻) on remote to cycle through come hither motion modes
- Press **VIBRATION** (Ⓜ) to cycle through vibration modes
- TOMO II can be used without remote. Follow TOMO instructions to manually operate TOMO II.

Change Pattern Modes


Turn On/Off



Hold for 3s



Come Hither
Motion Modes



Vibration
Modes



Remote control distance
5-10m




POWER/PULSE



VIBRATE

CHARGING



- Insert charging cable into DC charging port found on backside of device
- Plug USB cable into any 5.0V USB power adapter, computer input, or power bank
- LED light will flash while charging and stop when complete



CHARGING



COMPLETE




Fully charged
in 2 hours

REMOTE BATTERY

- Remote uses a 3V CR2032 battery
- To remove battery, twist back panel counterclockwise
- Use a small, flatheaded object to gently remove battery from slot
- Gently press replacement battery into slot until it locks in place
- Replace back panel and twist clockwise until locked

Open / Close



Open: Counterclockwise
Close: Clockwise



The Button
Battery

USAGE

Prior to inserting your GIDDI device, use a water-based lubricant to lubricate your anus and the device. Feel free to use your fingers to relax your sphincter muscle before insertion.


Many people enjoy using TOMO while lying on their back with knees up, or on their side in fetal position.

Carefully insert the primary head, ensuring that TOMO curves up towards your stomach.

The secondary head should be located below.

Never force insertion.

Stop immediately if you feel pain.



CLEANING, STORAGE & SAFETY

Always clean your GIDDI device before and after each use. Water-based lubricants are the best option for your device. Never use massage oils, lotion or cream as lubricants for intimate areas.

To clean, wash in warm water and a respected antibacterial soap, rinse with clean, hot water and pat dry with a lint free cloth or towel. Never use cleansers containing alcohol, petrol or acetone.

Store in the washable microfiber pouch provided. Avoid leaving your GIDDI device in direct sunlight and never expose it to extreme heat. Do not use on swollen or damaged skin. Keep your device out of the reach of children.


If your device appears to function abnormally, turn off and consult the FAQ section on **myGIDDI.com** or contact us at **hello@mygiddi.com**.

IMPORTANT INFORMATION

Disclaimer: Users of this GIDDI product do so at their own risk. Neither GIDDI nor its associated interests assume any responsibility or liability for the use of this product. GIDDI reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revisions or changes.

Disposal: This product should not be treated as household waste, but rather brought to the appropriate collection point for recycling of electrical and electronic equipment.

Applicable for all GIDDI products. Models may be changed without notice.



SPECIFICATIONS

- Materials: Medical Grade Silicone + ABS Plastic
- Size: 5.5 x 4.0 x 1.2 inches / 140 x 100 x 30 mm
- Weight: 4.6 ounces / 131 grams
- Battery: Lithium Ion 420mAH 3.7V
- Frequency: 50Hz
- Waterproof: 100%
- Charge Time: 2 hours at 5.0V / 300mA
- User Time: Up to 2 hours
- Standby: Up to 5 days
- Max Noise Level: <45db

Register for GIDDI Warranty by creating a customer account at

mygiddi.com/account. Questions? Contact us at hello@mygiddi.com



Designed in California. Made in China.
