



SIZING GUIDE

LONSDALE LEATHER BAND



SUITS WRISTS BETWEEN 168MM AND 225MM

HOW TO USE THIS GUIDE

Print and carefully cut out the watch to get a feel for the look and sizing on your wrist. Ensure your printer is set to print at 100% or 'actual size', and the watch will be printed at 1:1 scale.


HOW TO MEASURE YOUR WRIST

Cut along the dotted line of the ruler and use it to measure your wrist size.

FIND OUT MORE



Looking good! For more info visit melbournewatch.com.au/collections/lonsdale or scan the QR code on the left.





SIZING GUIDE

LONSDALE STEEL BRACELET



SUITS WRISTS BETWEEN 170MM AND 225MM

HOW TO USE THIS GUIDE

Print and carefully cut out the watch to get a feel for the look and sizing on your wrist. Ensure your printer is set to print at 100% or 'actual size', and the watch will be printed at 1:1 scale.


HOW TO MEASURE YOUR WRIST

Cut along the dotted line of the ruler and use it to measure your wrist size.

FIND OUT MORE



Looking good! For more info visit melbournewatch.com.au/collections/lonsdale or scan the QR code on the left.



27
26
25
24
23
22
21
20
19
18
17
16
15
14
13
12
11
10
9
8
7
6
5
4
3
2
1