MELBOURNE
WATCH COMPANY

CARLTON CHRONOGRAPH

Owner's Handbook

WELCOME TO OUR JOURNEY...

Thank you for purchasing your Melbourne Watch Company timepiece.

Since our establishment in 2013, we have strived to create timepieces of the highest quality that you as an owner can be proud of wearing.

Each MWC timepiece represents a new stage in our journey as a brand as we continue to grow – A journey that we are glad to have you on board for.

Sujain Krishnan
Managing Director, Founder

CONTENTS

CARLTON CHRONOGRAPH

The Carlton combines the old and the new with classic 1960s styling combined with a modern Swiss Made quartz chronograph movement.

The Ronda 5021.D chronograph allows for grab-and-go convenience, precise timekeeping and can function as a 30-minute stop watch through the chronograph function.

The Carlton also features an engraved relief of Melbourne's Royal Exhibition Building, a historic landmark located in the inner-city suburb after which the timepiece is named.

TECHNICAL SPECIFICATIONS

Case Material:	316L Stainless Steel
Case Diameter:	42mm
Case Thickness:	11mm
Lug Width:	22mm
Movement:	Ronda Cal. 5021.D (Swiss Made)
Battery Life:	3 years (standard)
Complications:	12 Hour Time, Chronograph
Crystal:	Flat Anti-Reflective Sapphire
Water Resistance:	50m/5ATM
Strap:	Padded Leather – 22mm

OPERATING INSTRUCTIONS

Your Carlton timepiece is fitted with the Ronda Cal. 5021.D quartz chronograph movement. An overview of functionality is shown below:

A. When partially pulled out, the crown can be rotated clockwise to quick-set the date.

B. When fully pulled out, the crown can be rotated to adjust the time. This also places the watch into battery saving mode.

C. The top pusher button stops and starts the chronograph timer

D. The bottom pusher button resets the chronograph timer

E. The central seconds hand will operate as a stop-watch seconds counter when in operation. By default, the chrono seconds hand will remain stopped at the 12 o'clock position

F. Chrono minute totaliser. This will count a total of 30 minutes per cycle when the chrono is active

F) CHRONO MINUTE TOTALISER

C) CHRONO START/STOP

A) DATE SET

B) TIME SET

D) CHRONO RESET

E) CHRONO SECONDS HAND

Notes:

1. DO NOT reset the chronograph seconds hand while the stopwatch function is running as this may cause damage to the mechanism.

2. The chronograph function can only count a maximum of 30 minutes per cycle. After this, it will stop.

WARRANTY & SUPPORT

Your 2 year warranty covers material production defects concerning the watch, strap and movement. It does not cover damage caused through misuse/ physical force, or normal wear and tear.

If you have an issue with your timepiece, please ensure you contact our customer service team prior to attempting any course of repair on your own, as dong so will render your warranty void.

To lodge a support request, please email your details along with a description of the issue to support@melbournewatch.com.au

This will create a support ticket within our helpdesk system and you will receive an automated email confirming receipt of your request, along with a case number which you can refer to during further correspondence.

For more information, or general enquiries, please refer to our website:

WWW.MELBOURNEWATCH.COM.AU/PAGES/CONTACT

STAY IN TOUCH

If you would like to keep up to date on our latest news and new model developments, you can subscribe to our newsletter on our website or follow us on social media.

facebook.com/melbournewatchcompany

@melbournewatch   #melbournewatch

pinterest.com/melbournewatch

MELBOURNE
WATCH COMPANY