



## RR1 (CRBR-2412io) (CRBR-2412) Parts List 2024.04.11

Drawing #	iio PART #	Description
0014	05-105544	Middle Door Hinge
0101	05-108164	Temp. Sensor Replacement Kit
1011	05-179683	Handle Base LH Swing
1011	05-179726	Handle Base RH Swing
1010	05-179728	Handle Screw
0136	05-188013	Door Bearing
0035	05-260862	Filter/Dryer
1012	05-279646	Handle
1320	05-407845	Bottom Door Shelf
1394	05-407979	Crisp Zone Drawer Only No Faceplate
1324	05-407996	Crisp Zone Faceplate
1324	05-408007	Crisp Zone Drawer Faceplate No Badge
1326	05-408228	Control Access Grommet
0109	05-409504	Door Pin Top Washer
82	05-409529	Door Stop RH Swing
0083	05-409530	Door Stop LH Swing
1321	05-409805	Egg/Ice Tray
1347	05-409806	Butter/Cheese Container
1348	05-409808	Bottom Door Shelf Trim
1345	05-409817	Glass Shelf Rear Trim
1346	05-409841	Glass Shelf Front Trim
43	05-410404	Condenser
1338	05-410410	Spacer
1323	05-410606	Wire Rack/Bottle Holder
1352	05-410812	Zero Zone Drawer No Badge
1353	05-410813	Zero Zone Trim
1355	05-410814	Crisp Zone Trim
1352	05-413027	Zero Zone Drawer
1388	05-413198	Air Channel Vent
1367	05-413243	Hall Sensor Holder
1327	05-413276	Lower Freezer Drawer Cover
1319	05-413279	Spacebox Glass Cover
0001	05-420268	Hinge Hole Plug
0069	05-421098	Screw Cap
1318	05-433234	Glass Shelf
1325	05-433265	Crisp Zone Wheel Assembly
1360	05-443163	Lower Air Duct Cover
0195	05-449224	Door Pin Washer

1322	05-458677	Bottle Retainer
1364	05-459916	Recirculating Fan Cover
0336A	05-461751	Lower Door Gasket (White)
0336A	05-467726	Lower Door Gasket (Black)
0336	05-467832	Upper Door Gasket (White)
0336	05-467834	Upper Door Gasket (Black)
0041	05-474360	Adjustable Leg
0212	05-494338	Compressor Electrical Assy
1361	05-494425	N/A
1344	05-497664	Crisp Zone Cover
1479	05-498660	ZeroZone Drawer Wheel
1317	05-510818	SimpleSlide Shelf No Badge
1330	05-512477	Crisp Zone Humidity Control
1317	05-512818	SimpleSlide Shelf
1518	05-513385	Upper Door Hinge RH Swing
1503	05-513386	LH Placeholder
1501	05-513387	Lower Door Hinge
1329	05-513997	LED Light
1519	05-515860	Upper Door Hinge LH Swing
1507	05-544929	Upper Door RH (Cream)
1508	05-544938	Lower Door RH (Cream)
1328	05-544947	LED Light Housing
1336	05-544960	Right Display Cover
1342	05-544961	Left Display Cover with No Frost Badge
1362	05-544971	Recirculating Fan Assembly
1340	05-545026	Condensation Reservoir
1349	05-545028	Condensation Reservoir Cover
1365	05-545054	Evaporator
1369	05-545128	Power Board
1425	05-545134	Control/Display
0214	05-545476	Capacitor
1371	05-559779	Multi Flow 360
1507	05-562145	Upper Door RH (Black)
1508	05-562161	Lower Door RH (Black)
1507	05-562213	Upper Door RH (Bordeaux)
1508	05-562217	Lower Door RH (Bordeaux)
1498	05-562231	Fridge Cap (Bordeaux)
0188	05-562798	Wiring Harness
1125	05-570361	Zero Zone Rail Right
1126	05-570363	Zero Zone Rail Left
1331	05-571770	Spacebox Drawer Assembly
1332	05-571771	XtremeFreeze Drawer Assembly No Badge
1333	05-571772	Lower Freezer Drawer Assembly
1332	05-571773	XtremeFreeze Drawer Assembly
1331	05-571785	Spacebox Drawer No Faceplate
0737	05-662161	Temperature Sensor Cover
1498	05-686437	Fridge Cap (Black)

1498	05-686441	Fridge Cap (Cream)
0209	05-693104	Power Cord
0041A	05-697782	Leg
0043	05-705580	Condenser
0210	05-710226	Compressor
1370	05-792097	Hall Sensor
1507	05-833781	Upper Door LH (Cream)
1508	05-833805	Lower Door LH (Cream)
1507	05-833852	Upper Door LH (Bordeaux)
0336A	05-833865	Lower Door LH (Bordeaux)
1507	05-833869	Upper Door LH (Black)
1508	05-833872	Lower Door LH (Black)
0026	05-842195	iio Logo