

Anti-Tip Device for Storage Furniture



SKU CODE TBC


WARNING: FURNITURE TIPPING RISK - PLEASE READ CAREFULLY

Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent this item of furniture tipping over, please follow this advice and attached as advised:

- **Attention!** This kit acts as a deterrent and cannot replace adult supervision. Never leave any young child unattended.
- Using this kit, please ensure you secure this furniture product to the wall for you and your family's safety, before you use it.
- Do not let children climb or hang on drawers, doors or shelves.
- Always place the heaviest items in the lower drawers or shelves
- Do not place TV's or other heavy objects on top of this product, unless it has been specifically designed to support them.
- Never open more than one drawer at a time
- DO NOT use power tools to apply the brackets to the furniture. Please use a Phillips / cross head screw driver.
- Please check the kit regularly to ensure it is safe to use and works correctly. If worn or damaged, please disregard and replace with a new kit to ensure safety is considered at all times.

Component Check List

		
4x Brackets	2x Screws 20mmL	2x Cable Ties
You will need (not supplied) 2x suitable screws for your wall type to secure furniture	You will need (not supplied)  Phillips Head Screwdriver	



STEP 1:

Screw two brackets to the back of the furniture using the hardware provided. There should be one at each end of the unit (unless it is a small unit, such as a bedside table).

STEP 2:

Please use fixings that are suitable for the walls in your home, they are **NOT** provided in this hardware pack. If in any doubt, please seek professional advice.


Place the piece of furniture in desired location and mark the wall with the position of the required drill hole/s. Remove the piece of furniture before drilling the hole/s and fixing the wall brackets in place using the hardware suitable for the walls in your home.

Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.



STEP 3:


Reposition the piece of furniture so the brackets on the unit and the wall align and are as close together as possible.



STEP 4:

Loop the cable tie through the holes of both the wall and furniture brackets (keeping the ridges of the cable tie on the inside) and push the cable tie through the end to lock. Tighten the cable tie as fully as possible to secure. Repeat for second set of brackets.

If/When you need to move the furniture, please release the clip on the cable tie to loosen and remove it. The cable ties we have provided are releasable and therefore re-usable. Once the furniture is back in place, please re-instate the cable ties to re-secure your furniture.



Should you need a replacement kit, please contact us on: 0344 848 6000