




gltc.co.uk

Children's Teepee



Thank you for shopping with GLTC, we hope you enjoy having this product in your home.

We know assembling furniture, toys or accessories is not everyone's favourite way to spend their time, so we've tried to make assembling this item as quick and painless as possible.

Hopefully our efforts will have been worthwhile and you'll sail through the whole process.

A few important pointers before you start:

- It might be worth checking on our website that there are no updates or revisions to these instructions (if we have had helpful feedback from other customers we pass it on via the product web page). Simply check the date and version number on the front of this leaflet against that of any site updates.
- Please read the instructions right through before you start, and check that all the components have been included in the pack; we find separating all the hardware into piles makes it easier to be sure that everything is present and correct.
- Do not throw away any packing materials until assembly is complete, just in case you accidentally discard smaller parts or hardware.

Assembly Difficulty



easy - medium - hard



one-person job

V3

12/10/2018

Safety Warnings!

- WARNING! Not suitable for children under 3 years due to small parts which may become detached and present a choking hazard.
- WARNING! STRANGULATION HAZARD - Long cord. Not for children under 3 years.
- WARNING! KEEP AWAY FROM FIRE!
- CAUTION Adult assembly required. Assembly to be carried out by a competent adult only. During assembly children should be kept away from the product and all packaging disposed of due to possible risk of injury.
- IMPORTANT! The putting up and taking down of this product should always be done by an adult.
- Do not use this item if any components are missing or damaged.
- WARNING! Do not use near overhead power lines or during thunderstorms.
- Always place on a cleared flat surface away from sharp objects, stones obstacles and furniture.
- Not waterproof or made for camping.
- For family domestic use only. Suitable for indoor or outdoor use.
- Please retain this information for future reference.

Customer Service:

- If you find that any components are missing or damaged, please do not begin assembly and do not use the item. Please contact GLTC Customer Services on **0344 848 6000** immediately.
- We do stock spare parts at our warehouse, so we should be able to send you a replacement part immediately if required.

Product Care:

- Poles: Wipe clean using a soft damp cloth followed by a dry cloth.
- Do NOT use cleaning products which contain ammonia, solvents or abrasive material.
- Wigwam Canvas: Spot clean with a mild detergent and allow to dry naturally before storing.
- Please follow wash care instructions on the product sew in labels. Please note that only the groundsheet is machine washable.






Could we do better?

If there is anything you think could be improved in these instructions or in the assembly of this product we'd be grateful if you could let us know; we'll pass any helpful hints and tips on to other customers via our website and update the instructions.

All you need to do is drop us a line at instructions@gltc.co.uk



Thank you

Component Check List

<p>A</p>  <p>1x Wigwam Canvas (spot clean)</p>	<p>B</p>  <p>4x Pole Base section</p>	<p>C</p>  <p>4x Pole Top section</p>
<p>D</p>  <p>1x Cotton Cord</p>	<p>E</p>  <p>1x Ground sheet (machine washable)</p>	

STEP 1:

Push the metal pole sections together until secure.





STEP 2:

Insert the four assembled metal poles into the four canvas side channels.

Please ensure the holes at the pole tops are at the top of the wigwam when the poles are inserted into the channels.

STEP 3:

Attach the metal poles and canvas together at the top using the cotton cord. Starting at the front, thread the string through the eyelet in the canvas and then through the hole at the top of the pole. Repeat until all poles are attached to the canvas. Secure the string with a knot or bow.



STEP 4:

Spread out the ground sheet inside the wigwam. Fix in place by threading the ties through the eyelets at the base of each pole and secure with a knot or bow.

The assembly is now complete.