


Loading Graphics into Freestanding and Wall Mounted Light Panels



- To load the graphics into you Freestanding Light Panel remove the frames on the front of the display by gently sliding the pocket up.
- Slot the graphic in.
- With your graphic in the pocket slot the top of the pocket into place first.
- Then slide the pocket down slightly. This will locate the pocket into the correct position and stop it from falling out.

N.B

The thumb hole identifies the top of the pocket .