



Elska Wall Mount Reading Lamp




E12 candelabra base bulb
not included

Contents



1. Mount the universal crossbar directly to the junction box using x2 of the provided #8-32 screws.
** The tapped holes that are a 2.75" spacing must end up horizontal to each other in order to mount the fixture in the next step.*



2. Hold the fixture backplate close to the wall and connect the fixture ground wire to the wall ground wire.
3. Connect the +/- fixture wires to the +/- wall wires.
4. Slide the fixture backplate onto the universal crossbar.
5. Secure the fixture backplate to the universal crossbar by turning the thumb screw until the fixture nipple is completely threaded through the universal crossbar.

