

Brand	Model	RULER FOOT
BABYLOCK	BL1000, BL1050, BL1108, BL1400, BL1500, BL1506, BL1550, BL1556, BL1750, BL200, BL2100, BL2150, BL2160, BL2200, BL2300, BL2400, BL2500, BL2600, BL2800, BL3500, BL500, BL5500, BL6000, BL6150, BL6200, BL6300, BL6600, BL6700, BL6800, BL702, BL713, BL722, BL7500, BL8000, BL8500, BL9500, EM1, EM2, ES1, ES2, ESE, ESP, & Quilter Choice, Babylock Symphony, Babylock Serenade, Babylock Espire, Soprano, Ellisimo, Melody	super LOW Shank
	Elageo, Aria, Crescendo, Destiny, Unity, Journey, Spirit, Solaris	HIGH SHANK
	Jane, Quilters Choice Pro	Not Available
BERNETTE	A series (model Milan 2, Milan 3, Milan, 5 Milan 7, Milan 8, Moscow 2, Moscow 3, Moscow 5, Moscow 7, Moscow 8, Rome 3, Rome 5, Rome 7, Rome 8) B series (model London 2, London 3, London 5, London 7, London 8) C series (model Chicago 5, Chicago 7) D series (model 340 Deco, 340 Deco Plus) E series (model Sew&Go 1, Sew&Go 3, Sew&Go 5, Sew&Go 7, Sew&Go 8) F series (model B30, B33, B35, B38) Sew Pink	LOW Shank
	OLD STYLE MACHINES (GENERALLY BEFORE 1996) 500, 530, 532, 534, 540 600, 610, 640, 642, 644 900, 910, 930, 931, 932, 940, 950 1000, 1001, 1004, 1005, 1006, 1008, 1010, 1011, 1015, 1020, 1030, 1031, 1080, 1090, 1120, 1130, 1230, 1260, 1530, 1630, 1640, 1650 700, 707, 708, 709, 717, 718, 719, 730, 731, 732, 740, 741, 742, 744 800, 801, 802, 803, 807, 808, 809, 810, 811, 817, 818, 819, 830, 831, 832, 840, 841, 842, 850. 710, 720, 740, 750QE, 770QE, 790, 820, 830, 880	super LOW Shank
BERNINA	NEW STYLE MACHINES 100, 120, 130, 140, 190, 530, 550QE, 560, 580, ACTIVA 125, 125S, 135, 135S, 145, 145S, 210, 215, 220, 230, 230PE ARTISTA 165, 170, 180, 185, 200, 630, 635, 640, 730 AURORA 430, 435, 440QE, 450 VIRTUOSA 150, 153, 153QE, 155, 160, 163	super LOW Shank
	All Brother models are super low shank EXCEPT: SA131, F010N, XA6126-002, XA6126001, #XA6027001 - Super ACE +e, PC6500, PC8200, PC8500, PC8500D, Super Galaxie 2000, Super Galaxie 2100, Super Galaxie 2100D, Super Galaxie 3100, Innov-is V5, Innov-is V7, VQ2, Innov-is 2800D, Innov-is 2500D, Innov-is 1500D, PE8500 THESE MODELS WILL WORK IF YOU USE THE ADAPTOR "S" that came with your machine, then you will use the super low shank ruler foot. ULT 2001/2002/2003, VM2200, VQ2400, VQ3000, VM5100, VM6200, XV8500D, XP1, BQ2450, BQ3050	super LOW Shank
BROTHER	ULT 2001/2002/2003, VM2200, VQ2400, VQ3000, VM5100, VM6200, XV8500D, XP1, BQ2450, BQ3050	HIGH SHANK
	eXcellence 580, 680, 720, 720PRO, 730, 730PRO, 760, 760PRO, 780, eXpressive 860, 900, 920, 8006, 9006, e9500, 9600, CE20, enVision 9006, eXperience 680 old style model (352, 354, 507, 508, 509, 511, 515, 516, 521, 525, 530, 531, 532, 535, 538, 539, 541, 543, 545, 551, 552, 574, 577, 580, 589, 656A, 675, 888, 921, 960, 1354, MK9) Category C (model XC500, MC5000, MC5700, MC6600, MC6600P, MC7700 Horizon, MC7700QCP, MC8000, MC8100HF, MC9000, MC9500, MC9700, MC10000, MC10001, MC11000 Special Edition, MC11000, MOD-15, MOD-19, SkyLine S3, SkyLine S5, Skyline S7, Atelier 3) Category D (model MC6700P, MC 8200QC, MC 9400QCP, MC9900, MC12000, MC14000, MC15000, HORIZON MC8900QCP, Atelier 5, Atelier 7, Atelier 9)	HIGH SHANK
Elna	Sew Green, Sew Fun, Sew Zebra, Sew 75, En Vision CE20, 2002, 2004, 2006, 2110, 2130, 2600 BLUE, 2800 BLUE, 3003, 3005, 3007, 3008, 3210, 3230, 5000, 5100, 6000, 6001, 6003Q, 6004, 6005, 7000, 7200 PRO, 8000, eXplore 150, 160, 220, 240, 320, 340, Lotus 2, eXperience 520, 540, 550, 560, 570, 580, 620	super LOW Shank
	ALL MODELS	super LOW Shank
EVERSEWN	Hobby10, Hobby140, Dorina 308, Dorina 323, Dorina 333, Tipmatic 1035-DFT, Tipmatic 1037, Tipmatic 6122, Tipmatic 6152	LOW Shank
GRITZNER	Model Old style model (1017 Harmony, 601, 602, 632, 623N, 623R, 635C, 636, 637, 639 Jem (Argos 555) 641, 648, 649, 653, 667, 668, 672, 674, 678, 680, 690, 691, 692, 693, 696, MK2, MK5 MK8, MK12) Category A (model 100-110, 1000CS, 1004, 1012A, 1014, 1018S, 1220, 1308, 1312, 1406, 1408, 1410, 1504, 1508, 1512, 1550, 1560, 1571, 1580, 1585, 1714, 1722, 1780, 1804, 1814, 1818, 1822, 1918, 2015s, 2015a, 2023, 2032, 2039, 2041, 2050, 2060, 2070, 2080, 2090, 2139, 2200XT, 2300XT, 300-372, 3300, 3816, 3822, 4400, 415, 419s, 423s, 609, 620, 623, 626 628, 655, 656a, 656b, 657, 657a, 660, 808, CJ14, CJ24, COMBI, COMBI-10, DM21, DE25, DE1800, ENX24, ES14N, J1012, J1024, J3-18, J3-20, J3-24, M50QDC, M100QDC, NOV3000, NOV4000, RX18S, SIMPLICITY, S2600, XLII, 813, LSM100, LSM200, SMD110, SMD500, SMD1000, XR-23, PS1024, PS1030, RE1318, DM1000, DM1118, DM1018, DM1108, DM1800, DMX200, DMX300 LX180, John Lewis JL110, Decor Excel DEX 20 & 25, JL100, JL125, JL200, J1024, JR1012, JL110, JL110SE, JL170)	super LOW Shank
JANOME	old style model (352, 354, 507, 508, 509, 511, 515, 516, 521, 525, 530, 531, 532, 535, 538, 539, 541, 543, 545, 551, 552, 574, 577, 580, 589, 656A, 675, 888, 921, 960, 1354, MK9) Category C (model XC500, MC5000, MC5700, MC6600, MC6600P, MC7700 Horizon, MC7700QCP, MC8000, MC8100HF, MC9000, MC9500, MC9700, MC10000, MC10001, MC11000 Special Edition, MC11000, MOD-15, MOD-19, SkyLine S3, SkyLine S5, Skyline S7, Atelier 3) Category D (model MC6700P, MC 8200QC, MC 9400QCP, MC9900, MC12000, MC14000, MC15000, HORIZON MC8900QCP, Atelier 5, Atelier 7, Atelier 9)	HIGH SHANK
	JL110, JL111, JL220	LOW Shank
JOHN LEWIS	JL110, JL111, JL220	LOW Shank

Brand	Model	RULER FOOT
JUKI	TL series (model TL2000QI, TL-2010Q, TL-2200QVP Mini, TL-98E, TL-98P, TL-98Q, TL-98QE)	HIGH SHANK
	70HW-A, 80HP-A, 353ZR-C, 355ZW-A DX series HZL (model DX5, DX7) F series HZL (model F300, F400, F600) G series HZL (model G120, G220) LB series HZL (model 5020, 5100)	LOW Shank
PFAFF	All except below	super LOW Shank
	1197, 1199, 1200, 1209, 1211, 1212, 1213, 1214, 1215, 1216, 1217, 1221, 1222, 1222E, 1222SE	HIGH SHANK
	2010, 2014, 2020, 2022, 2028, 2023, 2024, 2025, 2026, 2027, 2029, 2030, 2034, 2036, 2038, 2040, 2042, 2044, 2046, 2048, 2054, 2056, 2058, 2027, 2124, 2130, 2134, 2140, 2144, 2154, 2170, 2200, 6091, Creative Icon, Creative Sensation Pro, Creative Sensation, Creative Vision, Creative Performance, Creative 1.5 / 2.0 / 3.0 / 4.0 / 4.5, Performance 5.0 / 5.2, Quilt Expression 2.0 / 3.0 / 3.2 / 4.0 / 4.2, Expression 150	LOW Shank
SINGER	331 K1, 31-15, 20U	HIGH SHANK
	Inspiration series (4210, 4220, 4228)	super LOW Shank
	Futura series (100, 200, 6010, 9000)	
	Merritt series (1872, 1873, 2517, 2108, 3014, 3130, 3145, 3314, 3317, 4525, 4526, 4528, 4530, 4538, 6021)	
	Fasion Mate series (14C, 17, 22C, 237, 248, 257, 288, 360, 362, 7256)	
	Millennium series (6408, 6412, 6416, 6423,	
	Tradition series (2250, 2259, 2277,	
	Scholastic series (5511, 5523, 6510, 8280)	
	Confidence series (7463, 7467, 7467S, 7469Q, 7470)	
	1019, 1021, 1022, 1025, 1027, 1103, 1105, 1106, 1108, 1116, 1120, 1130, 1200-1, 1247N, 1260, 1263N, 127, 127-12, 127-3 Vibrating Shuttle, 128, 1280N, 1288N, 132Q FEATHERWEIGHT®, 13400, 1409 Promise, 15 Class, 15-125, 15-30, 15-86, 15-87, 15-88, 15-90, 15-91, 15-96, 15-97, 1500 Izek, 1507WC, 1525, 1725, 185, 1800 series (1800, 1802, 1803, 1812, 1852, 1862)	
2020, 2102, 2105, 2106, 2010 Superb, 2110, 2112, 2114, 2118, 2202, 2263 Simple, 2273 Esteem II, 2302, 2303, 2304, 2315, 2330, 2404, 2430, 2440, 2600, 2601, 2602, 2603, 2604, 2605, 2615, 2616, 2623, 2628, 2630, 2638, 2643, 2662, 27 Vibrating Shuttle, 2732, 2932, 293B, 200 series (200, 201, 201-2, 202, 203, 204, 205, 206, 206K, 207, 208, 209, 210, 212, 213, 214, 215, 216, 217, 218, 219, 220, 221 FEATHERWEIGHT®, 221 Quilter, 222, 223, 224, 227, 228, 237, 239, 240, 242, 244, 247, 247AP, 250, 252, 254, 258, 259, 263), 2500 series (2500, 2503, 2504, 2515, 2530, 2543)		
301, 301A, 401, 401A, 403, 404, 414, 423, 500, 500A, 503, 600, 600E, 603, 604, 609, 620, 625, 626, 628, 629, 630, 635, 636, 638, 640, 645, 646, 648, 649, 750, 756, 758, 774, 776, 770, 775, 776, 714, 734, 900, 920, 925, 1000, 1030, 1036, 1100, 1200, 1411, 1425, 2000, 2000A, 2001, 2005, 2010, 30920 4552, 4562, 4572, 4610, 4622, 5910, 6233, 6234, 6235, 6267, 6268, 6740, 6800, 6900, 7028, 7033, 8019, 9005, 9008, 9010, 9012, 9015, 9018, 9020, 9022, 9027, 9030, 9032, 9034, 9044, 9123, 9133, 9135, 9137, 9143, 9210, 9217, 9224, 9240, 9400, 9408, 9410, 9416, 9417, 9420, 9423, 9430, 9432, 9440 & 9444, 9900		
5 group (model Emerald 116, 118, 122, Prelude 340, 360, 350, 370 Prelude, Scandinavia 100, Daisy 335, 330, 325, 320, 315, 310, Oscar, Sophia, Emma, Lena, Romeo, Juliet, Anna, Sarah, 250, 230, 225/215, 210, 205, Jeans, Hugin, Tribute 145M)	super LOW Shank	
6 group (model Platinum 955 E, 950 E, Platinum Plus, Platinum 770, 775, Platinum 750 Quilt, 755 Quilt, 350, Platinum 730, 735, Platinum 715, Rose 600, 605, Iris, 400 Computer, Scandinavia 400, 300, 200, Interlude 445, 435, Lily 555, 550, 545, 540, 535, 530, 500, Freesia 445, 435, 425, 415, Lisa, Angelica, Viva, Victoria, 500, Facette 500/400, Emerald 122, 203, 183)		
7 group (model Brilliance 75Q, Designer Brilliance 80, Designer SE, Designer I USB, Designer I ESS, Designer I, Designer II, Designer Diamond, Designer Jade 35, Designer Diamond Royale, Designer Ruby, Designer Ruby deLuxe, Designer Ruby Royale, Designer Topaz 20, Designer Topaz 30, Designer Topaz 40, Designer Topaz 50, Designer SE Limited Edition, Eden Rose 250C, Opal 690Q, Opal 670, Quilt Designer, Quilt Designer II, Sapphire 875Q, Sapphire 875, Sapphire 870, Sapphire 855, Sapphire 850, Sapphire 835, Sapphire 830, Sapphire 930, Sapphire 960Q, Tribute 140C)		
8 group (model Designer Epic 980Q)		
VIKING		