



## Model #: 98071CCYZD INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

### CAUTION

**WARNING:** Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor. Min 90°C supply conductors.

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

### GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

## • ASSEMBLY AND INSTALLATION

**1. Carefully unpack and lay out the parts as shown in illustration and read all instructions before starting.**

2. Attach the mounting plate (7) to the outlet box by using two box screws (8).

3. Weave the power cord (13) through the steel ferrule (11), canopy (10), and mounting plate (7).

4. Determine needed length of power cord (13) to achieve desired fixture height. Secure the steel ferrule (11) using pull relief (12).

5. Pull out the outlet wire and ground wire from the outlet box (1). Make wire connections (5).

--Ribbed wire (w/o marking) from light to White wire (2) from power source


--Smooth wire (w/o marking) from light to Black wire (3) from power source

--Loop the ground wire (4) to mounting plate (7) with a ground screw (6)

6. Attach the canopy (10) to the mounting plate (7) by inserting the fixture mounting screws (9), and then secure

7. Follow instructions on line drawing for attachment of the shade to the hanging socket (A through C). It is recommended that shade assembly be completed before hanging and attaching the power wire to the outlet box

Summitland LLC Winston-Salem, NC USA E: [service@summitlandllc.com](mailto:service@summitlandllc.com)



1. OUTLET BOX
2. WHITE WIRE
3. BLACK WIRE
4. GROUND WIRE
5. WIRE CONNECTOR
6. GROUND SCREW
7. MOUNTING PLATE
8. BOX SCREW
9. MOUNTING SCREW
10. CANOPY
11. STEEL FERRULE
12. PULL RELIEF
13. POWER CORD
14. E26 SOCKET
15. LAMP SHADE
16. FIXED RING
17. E26 BULB ( EXCLUDED )