Volume

both

piezo

MIDI

It's not just for Strats!

You can add the Hexpander and the Acousti-Phonic to most electric guitars, and most Bass guitars too.

Program Up/Down Switch

Lets you instantly change the MIDI controller to the next patch without taking your hand off your guitar.

down


Ouick Switch

Plugged into the Hexpander, it lets you instantly select MIDI, piezo, or both at the same time; without adjusting volume controls!

MIDI Volume Pot

Lets you instantly change the MIDI controller's volume level without taking your hand off your guitar.

Tone



MIDI Volume

PK-0440-00 Hexpander Kit

PE-0440-00 Hexpander MIDI Adapter PE-0181-00 Hexpander Volume Pot

Magnetic

PE-0111-00 Quick Switch with Wiring Harness PE-0180-00 Program Up/Down Switch

1/4" Output Jack

Electric Guitar Amp

Mono Cable