

# Instructions for assembling the TV

## CONTENTS

Your TV includes 9 cardboard pieces;

- 1x main box-TV unit,
- 2x bases-TV stand
- 4x base supports,
- 1x antenna
- 1x antenna support

## MAIN BOX

Starting with the TV Box, you may find it useful to pre-press all fold lines especially the 6 tabs that will be used to hold the box together.


NOTE: There is a smooth side and a side with faint lines. The side with the faint lines should end up on the inside.

Proceed to fold the box together and then place aside until the base has been made.




## BASE

There are two identical base pieces like this, again you may find it useful to pre-press all fold lines.




Join the two base pieces together, once joined unfold the flaps for a more secure join.





### **BASE SUPPORTS**


There are four identical base supports. They slide into the base and down to lock them into position.






### CONNECTING THE BOX TO THE BASE

The two flap you see in the top picture will be inserted into the larger slot on the base of the box, secured again by being pressed back out the smaller slot





### Connecting the antenna

The antenna consists of two pieces, the antenna and its support. It is to be secured to the top of the box.



Insert the smaller support in to the underside of the box's lid so that it appears as shown.



Now insert the antenna to the top of the box's lid so that it appears as shown. Both the antenna and its support form a cross if you look in under the lid.

**CONGRATULATIONS YOU HAVE NOW  
ASSEMBLED YOUR MODNPOD TV.**

Have fun and be as creative and imaginative as you can be. :)