

**HOW TO USE:**

1. Place the legs into the saucepot.
2. Press the Power Button.
3. The stirrer is preset to low speed. Press again for medium speed and again for high speed.
4. Once you are done stirring, press the power button again to turn off.

**WARNINGS:**

- The legs are dishwasher safe.
- Wipe the top portion clean with a damp cloth.
- Do not leave unattended.
- Take care with hot liquids.


**Instruction Manual****AUTOMATIC  
SAUCE STIRRER  
MR. OCTOPUS™**

Read through this entire instruction manual BEFORE using the **Mr. Octopus**. We're dedicated to bringing you well-designed products that make living fun and easy. We stand behind all our products and warrant this to be free from defects in workmanship and materials.

For service claims or questions please consult our website **ProtocolDesign.com**.

## PARTS:

1. Legs
2. Battery Cover
3. Stirrer
4. Power/Speed Button



PROTOCOL

## BATTERY INSTALLATION AND SET UP:

1. Twist the battery cover and pull.
2. Install 4 x 'AA' batteries according to indicated polarities.
3. Slide batteries back into the cover and turn to close.
4. Connect to the legs if not already connected.



PROTOCOL