Instruction Manual for Tabletop Air Hockey

Attaching Scorekeepers

- Remove the two scorekeepers from the plastic bags and place on each end of the air hockey table.
- Make sure to line up the pre-drilled holes on the air hockey table and the scorekeepers.
- Screws and a screwdriver are provided. Four screws are required to set up the scorekeepers.



- The battery compartment is located on the bottom of the air hockey table next to the power button.
- Use the provided screwdriver to loosen the compartment lid and lift to remove.
- Insert 8 'AA' batteries (not included) into the compartment according to indicated polarity.
- 4. Screw the compartment lid back on with the provided screwdriver.

Operation

- Switch the power button located on the bottom of the table to "ON" to start the wind mechanism.
- 2. Two pucks and two mallets are provided for your enjoyment.
- When you or an opponent sinks a shot into the hole on the scorekeeper, move the scorekeeper to track your points.

