Instruction Manual for Safe in a Book

Read through this entire instruction manual BEFORE using your

Safe in a Book. We're dedicated to bringing you well-designed products that make living fun and easy. We stand behind all our products and warrant this to be free from defects in workmanship and materials for 1 year from the date of purchase. For service claims or questions please consult our website ProtocolNy.com.

Using Your Book Safe:

- 1. Open safe.
- 2. Remove bag containing two (2) safe keys, open, and remove keys.
- 3. Place one key on key ring and store other key in location away from safe.
- 4. Place items to be protected inside safe. For best results, do not leave items loose and movable inside safe as this could make noise when "book" moves and draw attention. Pack with spare cloth if necessary to prevent items from moving and to protect electronic items.
- 5. Close safe door and lock with key.
- 6. Close "book" cover.
- Store book safe on bookshelf like a regular book.