


Assembly Instructions for Flat Panel TV Swivel Wall Mount with Articulating Arm



Parts Included:

- A) 1 TV Swivel Wall Mount with Articulating Arm
- B) Two plastic anchors
- C) Two heavy duty screws
- D) Four $\frac{3}{4}$ " screws
- E) Four $\frac{1}{2}$ " screws
- F) 4 washers

Wall Mount Assembly:

Make sure to use the studs in your wall before mounting the wall plate. Do not mount this product into the drywall.

1. Drill two holes into the wall taking care to measure the distances to fit the wall plate vertically (part A). Insert the two plastic anchors (B) into the holes and then affix the wall plate to the wall by inserting the two heavy duty screws (C) through the slots and into the anchors. Use a drill to secure.
2. Install the TV to the plate with the articulating arm by using parts D and E. Use the parts that fit your TV the best. The 4 washers (F) are provided to ensure a better fit.
3. Once the TV is installed, the articulating arm can fully extend for your viewing pleasure.

Warning:

- Use caution when hanging heavy objects.
- Hang only flat screen televisions on wall mount.
- Not for children.