

HOW TO USE:

Cut Style: Strip Cut

Shred Width: 5mm

1. Maximum capacity: 1 sheet standard copy paper folded in half.
2. Push the button to FWD.
3. Feed the paper into the shredder.
4. If a jam occurs, push the button to reverse and gently pull the paper out.
5. Keep in the OFF position when not in use.

WARNINGS:

- Avoid Injury: Keep fingers, long hair, neckties, jewelry, loose clothing, and other objects away from the shredder.
- Insert paper only. Any other objects will damage shredder.
- Do not get wet.
- Adult use only. Keep away from children.

Instruction Manual

PORTABLE
PAPER SHREDDER

**PAPER
GATOR™**



Read through this entire instruction manual BEFORE using the **Paper Gator**. We're dedicated to bringing you well-designed products that make living fun and easy. We stand behind all our products and warrant this to be free from defects in workmanship and materials.

For service claims or questions please consult our website **ProtocolDesign.com**.

PARTS:

1. Battery Compartment
2. USB Cable
3. USB Port
4. Power/FWD/REV



BATTERY OR USB INSTALLATION:

1. If using batteries, remove the battery cover and install 4 x 'AA' batteries according to indicated polarity. Replace the battery cover.
2. If using the USB cable, plug the cable into the port on the shredder and into a USB port.

