


Instruction Manual for Rebounding Putting Set



Putter:

Screw parts 1- 4 together as indicated in the below diagram.



Rebounding:

A. Battery Installation

Insert 2 "C" batteries according to correct polarities.

B. Rebounding Ball

The weight of the ball triggers the rebounding mechanism. You must "sink the shot" in order to have the ball returned to you.



Maintenance:

- Replace batteries when machine starts to run slow or stops working.
- Wipe case with a damp cloth if it gets dirty. Do not submerge in water.