Instruction Manual for Golfer's Set

Rangefinder, Multi Tool and Accessories

How to use the Rangefinder:

- The Rangefinder is a 4x10mm magnification monocular and measures the distance between you and a standard golf flag.
- Point the Rangefinder towards the golf flag while looking through the eyepiece. The scale shown inside should feature the word "Green" at the bottom (Fig.1).



- Turn the focusing knob located to the left of the eyepiece until the scale is crystal clear.
- Align the baseline of the scale to the bottom of the golf flag post.
- 5. The number that the top of the golf flag post touches indicates the distance between you and the golf flag. The distance in yards is shown on the left of the scale and the distance in meters is shown on the right of the scale.
- 6. The Rangefinder is also equipped with a stroke counter located to the right of the eyepiece. Simply press the button on the right side of the Rangefinder to advance the counter. The counter will cycle through 15 strokes before it reaches zero again.

Caution: Do not look directly into the sun with the Rangefinder.

