




**PLEASE READ THIS MANUAL**  
**SAVE FOR FUTURE REFERENCE**



## Operation

- **Mode:** this cycles between manual and your timer settings
- **OK key:** Press this after any changes to save your settings.
- **Clock:** Setting your current time, after pressing the clock key, set the time with the Up key and the Down key. Set the hour and then press clock again to change the minutes. Press the OK key after you have set it correctly to your time.
- **Timer:** Press the Timer key and the timing function icon will turn on. Then press the clock button to set your first timer. Repeat the operation to set up to 6 other timer settings total. Repeatedly press timer to cycle between the 6 timers.
- **Timer Off:** Set the off timer settings in the same way. Pressing timer will cycle between Timer 1 On, Timer 1 Off, Timer 2 On, Timer 2 Off, etc.
- **%:** Power Setting Key. Use this button to set your flow, press % key to set flow by UP key and Down key, ranges vary between 50%-99%. After that, press OK key to save and run.
- **ON/OFF key:** In automatic mode, this will start and stop the pump.
- **Power on:** If the display is asleep, press the power key. This will turn the remote on and restore the settings before the remote went asleep. When the remote wakes up it will send time, flow, automatic/timing data. In timing mode, it performs the start-up, or stop command according whether it is running.
- **Sleep:** The remote enters sleep after no operation for 30 seconds.
- **Press the "CLOCK" key** to set the time you want your timer to start the pump. When the time is not set, it displays "--:--". Press the "CLOCK" key again and the hour icon flashes, and the current time point can be set by pressing the "Up" or the "Down" key. Then press the "CLOCK" key, the minute icon flashes, and press the "Up" or "Down" key to set the current minute. The hour and minute both should be set. Press the "OK" key to save the time period.

## Troubleshooting

If your pump fails to start, try cycling between the power levels on the remote. Sometimes, pumps will not start up if the wattage is not sufficient.



**ATTENTION: ONLY OPERATE WITH ASYNCHRONOUS PUMPS**  
Never start up pumps unless submerged in fresh-water.

## LIMITED WARRANTY

Products manufactured by ANJON are warranted to the original user only to be free of defects in material and workmanship for a period of 24 months from the date of purchase, but not more than 30 months from the date of manufacture. ANJON liability under this warranty shall be limited to repairing or replacing, at ANJON's discretion, without charge, F.O.B. ANJON will not be liable for any cost of removal, installation, transportation, or any other charges which may arise in connection with a warranty claim.

Products which are sold but not manufactured by ANJON are subject to the warranty provided by the manufacturer of said product(s) and not by ANJON's warranty. ANJON will not be liable for damage or wear to products caused by abnormal operating conditions, accident, abuse, misuse, unauthorized alteration or repair, or if the product was not installed in accordance with ANJON's printed installation and operating instructions.

To obtain service under this warranty, the defective product must be returned to the distributor or dealer of ANJON's products from which it was purchased together with proof of purchase and installation date, failure date, and supporting installation data. Unless otherwise provided, the distributor or dealer will contact ANJON or an authorized service station for instructions. Any defective product to be returned to ANJON or a service station must be sent freight prepaid: documentation supporting the warranty claim and/or a Return Merchandise Authorization (RMA) must be included if so instructed. In the absence of suitable proof of purchase date, the effective date of this warranty will be based upon the date of manufacture.

Any replacement product may be either new or like-new, provided that it has functionality at least equal to that of the product being replaced. No requests for service under this warranty will be accepted if received more than 30 days after the term of the warranty. Correction of defects, in the manner and for the duration of the warranty described in this warranty, shall constitute complete fulfillment of all liabilities and responsibilities of ANJON to the user with respect to the product, and shall constitute full satisfaction of all claims, whether based on contract, negligence, and strict liability or otherwise. Except for the obligations specifically set forth in this warranty, in no event shall ANJON be liable for direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory and whether advised of the possibility of such damages.

ANJON reserves the right to change or improve its products or any portions thereof without being obligated to provide such a change or improvement for units sold and/or shipped prior to such a change or improvement. THERE ARE NO EXPRESS OR IMPLIED WARRANTIES, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, WHICH EXTEND BEYOND THOSE WARRANTIES DESCRIBED OR REFERRED TO ABOVE EXCEPT AS EXPRESSLY HEREIN PROVIDED THE GOODS ARE SOLD "AS IS", THE ENTIRE RISK AS TO QUALITY AND FITNESS FOR A PARTICULAR PURPOSE, AND PERFORMANCE OF THE GOODS IS WITH THE BUYER, AND SHOULD THE GOODS PROVE DEFECTIVE FOLLOWING THEIR PURCHASE, THE BUYER AND NOT THE MANUFACTURER, DISTRIBUTOR, OR RETAILER ASSUMES THE ENTIRE RISK OF ALL NECESSARY SERVICING AND REPAIR.

Some jurisdictions do not allow the exclusions or limitation of incidental or consequential damages and some jurisdictions do not allow limitations on how long implied warranties may last or require you to pay certain expenses as set forth above. Therefore, the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from jurisdictions to jurisdiction.

**Contact local electrician for assistance if needed.**

